


Installation Instructions

Mitsubishi Outlander Sport / RVR

Part Numbers:
36509
90210
06131



Do Not Exceed Lower of Towing Vehicle Manufacturer's Rating or

3500 Lb. (1589 kg) Max Gross Trailer Weight
300 Lb. (136 kg) Max Tongue Weight

Hitch Shown In Proper Position

Fastener Kit: 36509F

Equipment Required: N/A

Wrenches: 14mm, 17mm, 3/4 or 7/8

Wiring Access Location: SUV 1, SUV 2




Figure 1

Factory Tow Loop

①	Qty. (2)	Block .250 x 1.50 x 4.00 (2 square holes)	⑤	Qty. (2)	Bolt M10 x 1.25 x 30mm CL8.8
②	Qty. (4)	Carriage bolt 1/2-13 x 4.50 Long Gr5	⑥	Qty. (2)	7/16 Conical Washer
③	Qty. (4)	1/2 Conical washer			
④	Qty. (4)	Hex nut 1/2-13			

- Remove (3) bolts and factory tow loop from passenger's side frame rail. Return bolts and tow loop to vehicle owner..
- Insert carriage bolts and blocks into existing holes in the side of frame rails. Adjust carriage bolts to be flush with inside of frame rails.
 Note: On the driver's side, the carriage bolts are installed by reaching between the bumper fascia and over the top the carbon canister.
- Raise the hitch into position and push the carriage bolts through the holes in hitch. Loosely install the 1/2 conical washers and hex nuts onto carriage bolts.
 Tip: For ease of installation, raise the driver's side of hitch first, guiding the flange on side bracket around the carbon canister. Then raise the passenger's side into position.
- Loosely install the M10 hex bolts with 7/16 conical washers into existing weld nuts in the bottom of frame rails.
- First, tighten the 1/2-13 GR5 carriage bolts to specifications.
- Then, tighten the M10 CL8.8 bolts to specifications.

Tighten all 1/2-13 GR5 fasteners with torque wrench to 75 Lb.-Ft. (102 N*M)

Tighten all M10-1.25 CL8.8 fasteners with torque wrench to 42 Lb.-Ft. (57 N*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.