

# Installation Instructions

## Acura TL

Part Numbers:

**24755**

**77131**

**60814**

**24730 U-Haul**

**(Sold separately)**

**Drawbar Kit:**

3594


**Do Not Exceed Lower of Towing Vehicle  
Manufacturer's Rating or**

**2000 LB Max Gross Trailer Weight**

**200 LB Max Tongue Weight**

**Wiring Access Location: PC3, PC4**

Drawbar must be used in the  
**RISE** position only.




### Hitch Shown In Proper Position

#### Equipment Required:

**Fastener Kit: 24755F**


**Wrenches: 3/4", 10mm**

**Drill Bits: 1/2"**




**Figure 1**

#### **REMOVE SPARE TIRE BEFORE DRILLING**



**Figure 2**



**Orient Spacers As Shown**

**Figure 3**

①	Qty. (1)	Hex Bolt, 1/2"-13 x 2-1/2"	④	Qty. (3)	Hex Nut, 1/2"
②	Qty. (3)	Spacer, 1/4" x 1-1/2" x 2"	⑤	Qty. (2)	Carriage Bolt, 1/2"-13 x 1-3/4"
③	Qty. (3)	Lock Washer, 1/2"	⑥	Qty. (2)	Spacer, 1/4" x 1" x 2"

1. Remove the spare tire from the trunk.
2. Remove plastic cover under trunk by removing four plastic rivets connecting it to the fascia and two hex flange nuts connecting it to the trunk bottom. Reinstall the rivets and return the plastic cover and hex flange nuts to the vehicle owner.
3. Attach hitch to tow hook as shown in Figure 1. Orient the spacers with respect to the tow hook as shown in Figure 2 and Figure 3.
4. Using the hitch as a template, drill two 1/2" holes in the trunk pan.
5. Install the hitch to the trunk pan with the carriage bolts, spacers, lock washers and nuts as shown in Figure 1.
6. Seal the holes drilled in the trunk pan to prevent intrusion of exhaust fumes and water.
7. Reinstall the spare tire in the trunk.

**Tighten all 1/2" GR5 fasteners with torque wrench to 75 Lb.-Ft.**

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.