

Installation Instructions

**Honda Accord Sedan
Acura 3.2 CL & TL**

Part Numbers:

**24791
60913
77165**

Drawbar Kit:
3592
(Sold separately)

Drawbar must be used in the **RISE** position only.

Equipment Required:

Fastener Kit: 24791F
Wrenches: 3/4"
Drill Bits: NONE


**Do Not Exceed Lower of Towing Vehicle
Manufacturer's Rating or**

**2000LB (908Kg) Max Gross Trailer Weight
200 LB (90.8Kg) Max Tongue Weight**

Wiring Access Location: PC3



**Conical washer
Teeth side
against hitch**



Note: sort hardware prior to hitch installation.

①	Qty. (2)	BOLT – CARRIAGE 1/2"-13 X 1 1/2" GR 5	⑤	Qty. (3)	WASHER – CONICAL TOOTHED 1/2"
②	Qty. (2)	REINFORCING PLATE 1" X 3" X 1/4"	⑥	Qty. (1)	BOLT – CARRIAGE 1/2"-13 X 2-1/2" GR5
③	Qty. (2)	BOLT LEADER	⑦	Qty. (1)	SPACER 1" X 2" X 1/4" (SQUARE HOLE)
④	Qty. (3)	NUT 1/2"-13 GR5	⑧	Qty. (1)	SPACER 1" X 2" X 1/4" (ROUND HOLE)


- Lower exhaust by removing rubber isolators from muffler hangers.
- Thread bolt leader (3) onto 1 1/2" carriage bolt (1) and insert bolt leader through hole in reinforcing plate (2).
- Fish bolt leader (3) and assembly through access hole in bottom of frame and carefully pull down through proper hole in frame. (refer to "Access to Enclosed Frame" on last page of instruction sheet). Repeat for other side.
- Raise hitch up to vehicle and install 2" carriage bolt (6), along with square hole spacer (7) through vehicle's tie down hook, round hole spacer (8) and hitch's mounting tab in order as shown in illustration. Install conical toothed washer (5) and nut (4) and hand tighten to hold hitch in place. Fish bolt leaders through holes in frame straps and being careful not to push bolt assemblies back into frame channels, remove bolt leaders and install conical toothed washer (5) and nut (4).
- Tighten all 1/2-13 GR5 fasteners with torque wrench to 75 Lb.-Ft. (102 N*M)
⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.
- Raise exhaust back into position and reinstall rubber isolators.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

Installation Instructions

Access to Enclosed Frames



INSTRUCTIONS:

- 1 . Check to see if reinforcing plate and bolt head will fit through access hole, if not modify hole to accept hardware, the illustration above shows two ways of achieving this, the first is using a file, the second is by inserting a wrench or prying as shown. **Enlarge hole just enough to get hardware through.**
- 2 . Thread bolt leader onto bolt, insert loose end of bolt leader through hole in reinforcing plate. Fish bolt leader through access hole and attachment hole.
- 3 . Pull hardware into position, refer to illustration. **NOTE:** it is much easier if bolt and reinforcing plate are not engaged while inserting them into frame, refer to illustration.
- 4 . Proceed with installation of hitch as per instructions.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.