



! WARNING

To prevent SERIOUS INJURY, DEATH or PROPERTY DAMAGE:

- **ALWAYS read, understand and follow warnings and instructions for your hitch BEFORE installation. Keep for future reference.**
- **DO NOT cut, weld or modify this receiver.**
- **CHECK all fasteners are tight and your hitch is securely mounted to your vehicle periodically.**
- **ALWAYS read, understand and follow all warnings and instructions for your vehicle and for other accessories you will use with your hitch BEFORE use.**
- **LOAD the trailer heavier in front.**
- **DO NOT exceed lower of towing vehicle manufacturer's rating or:**

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	2000 lb. (908 kg)	200 lb. (90.8 kg)
Weight Distributing	X	X

- **ALWAYS wear your seatbelt.**
- **SLOW DOWN when towing, NEVER exceed any posted speed limit.**
- **If EXCESS SWAY occurs, take your foot off the gas pedal and hold the steering wheel as steady as possible. DO NOT apply your brakes and DO NOT speed up.**

LIMITED LIFETIME WARRANTY

1. **Limited Lifetime Warranty (“Warranty”).** Cequent Performance Products, Inc. (“We”, “Us” or “Our”) warrants to the original consumer purchaser only (“You” or “Your”) that the product will be free from material defects in both material and workmanship, ordinary wear and tear excepted. The Warranty is valid only if (a) the products are returned to Us for inspection and testing; (b) Our inspection discloses to Our satisfaction that any alleged nonconformance are material and have not been caused by misuse, neglect, wear and tear, improper installation, unsuitable storage, improper repair, alteration, or accident; and (c) the products were installed, maintained and used in accordance with Our instructions. THE WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (OTHER THAN THE WARRANTY OF TITLE AS PROVIDED BY THE UNIFORM COMMERCIAL CODE IN EFFECT IN MICHIGAN), INCLUDING WITHOUT LIMITATION, ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SAID WARRANTIES BEING EXPRESSLY DISCLAIMED.
2. **Obligations of Purchaser.** Any returned product that is replaced by Us becomes our property. You may be responsible for return shipping costs. Please retain your purchase receipt to verify date of purchase and that You are the original consumer purchaser. The product and the purchase receipt must be provided to Us in order to process Your Warranty claim.
3. **Exclusive Remedy.** Product replacement is Your sole and exclusive remedy under this Warranty. We shall not be liable for service or labor charges incurred in removing or replacing a product. IN NO EVENT WILL WE BE RESPONSIBLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES.
4. **Assumption of Risk.** You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.
5. **Governing Law.** This Warranty gives You specific legal rights, and You also may have other rights which vary from state to state. This Warranty is governed by the laws of the State of Michigan, without regard to rules pertaining to conflicts of law. The state courts located in Oakland County, Michigan shall have exclusive jurisdiction for any disputes relating to this Warranty.

Cequent™ Performance Products, Inc. Installation Instructions



PART NUMBERS: 24941, 77328, CQT24941

Applications:

Years	Make	Models
-------	------	--------

2016 -Current*	Chevy	Spark
----------------	-------	-------

*Visit our website for the most up to date information regarding application years and trim levels.


Installation Time: **45 min**

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.




Representative Vehicle Photo

Equipment Required:



DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	2000 lb. (908 kg)	200 lb. (90.8 kg)
Weight Distributing	X	X



Hitch Illustration

Authorized Drawbar Kit:

3593 (Sold Separately)

Drawbar must be used in the
RISE position only.

Installation Instructions

PART NUMBERS: 24941, 77328, CQT24941




Figure 1



Figure 2



Figure 3

NOTE: Fascia tabs are **not** centered on vehicle. **DO NOT** measure from tabs to locate area to trim.





Figure 4

Bottom View of Bumper Fascia

 Always wear SAFETY GLASSES when installing hitch

- 1. Remove fascia**
 - a.) using a 7 mm socket, remove (1) screw inside of rear wheel well, and (5) screws holding splash guard to fascia, both sides.
 - b.) using a flat head screw driver, remove (2) plastic retainers at the bottom center of Fascia.
 - c.) using a Phillips head screw driver, remove (2) screws holding tail lights to vehicle, both sides. Gently pull taillights rearward. Unplug wiring harness or remove bulbs from taillight housings. **NOTE:** Red wire is Top, Yellow wire is Center, and Blue wire is Bottom. See Figure 2.
 - d.) using a Phillips head screw driver, remove (2) screws holding fascia to vehicle, (1) per side.
 - e.) using a plastic trim panel tool, gently remove the plastic fascia starting at the wheel wells first. See Figure 3.
- 2. Remove bumper beam** – using a 13mm socket with extension, remove (6) flange nuts attaching bumper beam to end panel. See Figure 1.
- 3. Hitch installation** – raise hitch and bumper beam into position aligning holes with studs on the end panel. Sandwich the hitch between bumper beam and end panel. See Figure 1.
- 4. Reinstall fasteners** - Loosely reinstall the existing (6) flange nuts onto studs in end panel, (3) per side.
- 5. Tighten all fasteners with torque wrench to 20 Lb.-Ft. (27 N*M)**  Proper torque is needed to keep the hitch secure to the vehicle when towing.
- 6. Trim and reinstall fascia & splash guards** – measure, mark, and trim fascia as shown in figure 4. Reinstall fascia and splash guards.
- 7. Reinstall taillights and wiring** – reconnect the wiring and reinstall the taillights using the original (4) philips head screws, (2) per side.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.


1a. Remove fascia

using a 7 mm socket, remove (1) screw inside of rear wheel well, and (5) screws holding splash guard to fascia, both sides.



1b. Remove fascia

using a flat head screw driver, remove (2) plastic retainers at the bottom center of Fascia.



1c. Remove fascia

using a Phillips head screw driver, remove (2) screws holding taillights to vehicle, both sides. Gently pull taillights rearward. Unplug wiring harness or remove bulbs from taillight housings.

NOTE: Red wire is Top, Yellow wire is Center, and Blue wire is bottom.



1d. Remove fascia

using a Phillips head screw driver, remove (2) screws holding fascia to vehicle, (1) per side.



1e. Remove fascia


using a plastic trim panel tool, gently remove the plastic fascia starting at the wheel wells first.




2. Remove bumper beam – using a 13mm socket with extension, remove (6) flange nuts attaching bumper beam to end panel.



3. Hitch installation – raise hitch and bumper beam into position aligning holes with studs on the end panel. Sandwich the hitch between bumper beam and end panel.




4. Reinstall fasteners - Loosely reinstall the existing (6) flange nuts onto studs in end panel, (3) per side.




5. **Tighten all fasteners with torque wrench to 20 Lb.-Ft. (27 N*M)**

⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.



6. **Trim fascia – measure, mark, and trim fascia as shown.**



NOTE: Fascia tabs are not centered on vehicle. DO NOT measure from tabs to locate area to trim.




Figure 4

Bottom View of Bumper Fascia

7. **Reinstall taillights and wiring** – reconnect the wiring and reinstall the taillights using the original (4) phillips head screws, (2) per side.

