



## **51671-1121 & 51671-1122 1967-71 Australian Falcon Billet Hood Hinge Kit Installation Instructions**

If you plan to disassemble the hinges before installation, for polishing or plating, you should know that all the bolts are assembled with blue Loctite. This should be done again when the hinges are reassembled.

### **Packing List:**

- 2 – Hinge assemblies, one right and one left.
- 6 – 5/16" x 1-1/2" Button head bolts for attaching hinge body to inner fender.
- 4 – 5/16" x 1-1/4" Button head bolts w/ washers for steel hoods or 5/16" x 3/4" Button head bolts w/washers for fiberglass hoods. For attaching hinge bracket to hood.
- 2 – Gas springs

### **Tools needed:**

- 1/2" Socket, open end or box end for removing factory hinges.
- 3/16" Allen wrench for installing button head bolts.
- 11/32" and 3/8" Open end wrenches for hood adjustment height link.

### **Note:**

Check ALL bolt lengths for bottoming before tightening

---

## Installation steps:

1. Remove hood.
2. Remove factory hinges and try to hand tighten a button head bolt where each hinge bolt was removed. If the threads are damaged or corroded re-tap them. The holes in the fender liners are 5/16"-16 tap, in the hood 5/16"-18.
3. Position each hinge on the correct side and attach the hinge body to the inner fender with the 5/16" x 1-1/4" button head bolts. Use the two washers on the rear bolts. Before tightening the bolts completely move the hinge body up or down so the bolt is centered in the slot.
4. With the hinges in the lowered position measure between the fenders, across the hood brackets, and compare the spacing of the holes in the brackets to those in the hood. This may help in accurately positioning the hinges before the hood is bolted on.
5. Each hinge has a gas spring to hold the hood open. The gas spring should be attached to the hinge after the hinge is installed but before the hood is attached. The body, or thicker part of the spring should be attached to the ball stud at the higher point on the hinge so that the shaft will be oiled by gravity
6. Attach the hood to the hinges with the 5/16" x 1-1/4" button head bolts. Slide the hood forward as far as possible before tightening the bolts. This will assure that the hood will not hit the cowl as it is lowered. Lower the hood **carefully**, watching the clearance front and back as well as both sides. Adjust the hood on the hinge brackets as needed for the correct clearance.
7. Adjust the hood height. Once the hood closes completely, check the height of the hood at the rear corners. The hinges are shipped with the height adjustment in the lowest position so if the hood is too high lower the entire hinge on the inner fender. If the hood is too low raise it by adjusting the short link with rod end bearings. **Be aware that adjusting the height this way will also move the hood slightly forward so the hood may have to be repositioned on the hinge brackets.** Tighten the jam nuts when the adjustment is complete.