


MOUNTING BRACKET KIT

INSTALLATION INSTRUCTIONS

PARTS LIST:

- 1- LOWER RECEIVER (A) - Passenger side
- 1- LOWER RECEIVER (B) - Driver's side
- 1- MAIN BRACE (C) - Passenger side
- 1- MAIN BRACE (D) - Driver's side



IMPORTANT: All brackets *must* be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts *must* be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one.

- Use flat washers over all slotted holes
- Use lock washers on all fasteners

ROADMASTER Limited Warranty, including One-Year Conditional Warranty Text and Product Registration Card, in Carton.

WARNING

Failure to follow these instructions can result in property damage, personal injury or even death.

- Installation of most mounting brackets requires moderate mechanical aptitude and skills. We strongly recommend professional installation by an experienced installer.
- The installer must read the instructions and use all bolts and parts supplied. Failure to do so could result in loss of the towed vehicle.
- Use Loctite® Red on all bolts used for mounting this bracket.
- Do not use this document for custom fabrication, as it may not show all parts or structural components. Custom fabrication or an attempt to copy this bracket design could result in loss of the towed vehicle.
- Every 3,000 miles, the owner must inspect the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions. The owner must also inspect all mounts and brackets for cracks or other signs of fatigue every 3,000 miles. Failure to do so could result in loss of the towed vehicle.
- The owner must check the vehicle manufacturer's instructions for the proper procedure(s) to prepare the vehicle for towing. Some vehicles must be equipped with a transmission lube pump, an axle disconnect, driveline disconnect or free-wheeling hubs before they can be towed. Failure to properly equip the vehicle will cause severe damage to the transmission.
- If running changes were made by the vehicle manufacturer after this bracket was designed, some bolts or other fasteners in the hardware pack may no longer be the correct size. It is the installer's responsibility to verify that the bracket is securely fastened to the vehicle and fitted with the correct hardware to account for these changes. Failure to securely

fasten the bracket could result in loss of the towed vehicle.

- If the towed vehicle has been in an accident, it must be properly repaired before attaching the bracket. Do not install the bracket if any structural frame damage is found. Failure to repair the damage could result in the loss of the towed vehicle.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or bracket while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system, motorhome and/or towed vehicle.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. Refer to the cable instructions for proper routing. Failure to leave enough slack in the safety cables, or failure to connect the safety cables frame to frame, will result in the loss of the towed vehicle.
- This bracket is designed for use with ROADMASTER tow bars and ROADMASTER adaptors only. Using this bracket with other brands, without an approved ROADMASTER adaptor, may result in non-warranty damage or injury.
- Upon final installation, the installer must inspect the bracket to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc., or non-warranty damage to the towed vehicle will result.
- This bracket is only warranted for the original installation. Installing a used bracket on another vehicle is not recommended and will void the warranty.

MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT NO. 1217-2

- Important:** please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, begin the installation. This bracket kit is an XL Series quick disconnect bracket set consisting of two receiver braces, two detachable front braces and a hardware kit. There are also four mounting plates. The receivers will bolt behind the bumper using the front bumper mounting bolts as attachment points. Start the kit installation by removing two reflectors on the front of the bumper. These can be pried out using a small screwdriver. This will expose the bumper mounting bolts and the screw in tow bolt on the passenger side. *Note:* some vehicles may have fog lights in this area and they will have to be removed.
- Start on the passenger side first. Remove the 8mm bolts directly accessed through the front of the bumper. Hold a ¼" mounting plate with the large round hole over the welded nut assembly and bolt in place using two supplied 8mm x 1.25 x 35mm bolts and lock washers.
- Insert the passenger side receiver through the front of the bumper and bolt through the mounting plate using two ½" x 1½" bolts, lock washers and nuts.
- Bolt the ¼" mounting plate to the back of the receiver using two ½" x 1½" bolts, lock washers and nuts. Be sure the plate is under the frame.
- Check to be certain everything is aligned. Then, using the plate as a template, drill two ½" holes through the frame. Be careful not to drill through anything on the top side of the frame.
- Bolt through the mounting plate and the frame with the two supplied ½" x 5" bolts, lock washers and nuts. *Note:* be sure to use the triangular backing plate on the top of the frame.
- Follow steps 2 through 6 for the drivers side. *Note:* the driver's side will not have the welded tow nut.
- Install the front braces in the receivers and secure with the included 5/8" draw pins and spring pins. Now, tighten all bolts to the torque specifications below.
- Mount the tow bar according to the manufacturer's instructions.
- Save the 8mm bolts and reflector covers for dismounting the braces at a later date. *Note:* the tow vehicle's safety cables must be attached to the receiver braces with the quick links and safety cables provided.

HARDWARE LIST

4-8MM X 1.25 X 35MM BOLTS	12-1/2" NUTS
4-8MM LOCK WASHER	2-5/8" DRAW PINS
8-1/2" X 1 ½" BOLTS	2-1/8" SPRING PINS
4-1/2" X 5" BOLTS	2-QUICK LINKS
12-1/2" LOCK WASHERS	2-15" SAFETY CABLES

11-12-04
RV

BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS			METRIC BOLTS			METRIC BOLTS		
Thread Size	Grade	Torque	Thread Size	Grade	Plated/Unplated	Thread Size	Grade	Plated/Unplated
5/16	5	13 ft./lb.	8mm-1.0	8.8	20 ft./lb. 18 ft./lb.	12mm-1.25	8.8	70 ft./lb. 65 ft./lb.
3/8	5	23 ft./lb.	8mm-1.25	8.8	19 ft./lb. 18 ft./lb.	12mm-1.5	8.8	66 ft./lb. 61 ft./lb.
7/16	5	37 ft./lb.	10mm-1.25	8.8	38 ft./lb. 36 ft./lb.	12mm-1.75	8.8	65 ft./lb. 60 ft./lb.
1/2	5	56 ft./lb.	10mm-1.5	8.8	37 ft./lb. 35 ft./lb.	14mm-2.0	8.8	104 ft./lb. 97 ft./lb.
5/8	5	150 ft./lb.						