




MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



ITEM	QTY	NAME	PART #
1	4	12mm x 1.5 x 110mm BOLT	357113-00
2	4	12mm LOCK WASHER	355725-00
3	4	1" x 0.188 WALL x 1/4" PIPE SPACER	A-001022
4	2	1/2" x 2 1/2" BOLT	350099-00
5	6	1/2" LOCK WASHER	350309-00
6	2	1/2" PLATE WASHER	350351-00
7	4	1/2" x 1 1/4" BOLT	350094-00
8	4	1/2" NUT	350258-00
9	2	#10 x 3/4" SELF TAPPING SCREW	350247-35
10	1	WIRE PLUG PLATE	A-003801
11	1	DRIVER SIDE ARM	C-002782
12	1	PASSENGER SIDE ARM	C-002783
13	1	DRIVER SIDE MOUNTING BRACE	C-002787
14	1	PASSENGER SIDE MOUNTING BRACE	C-002788
15	1	MAIN RECEIVER BRACE WELDMENT	C-002904



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4

This is one of our EZ4 series brackets, which allows the visible front portion of the bracket to be easily removed from the front of the vehicle (Fig.A and Fig.B). The bracket consists of a main receiver brace, two removable front braces, and a hardware pack.

This bracket assembly mounts to the frame rails and the bumper core. The removable front braces install in the main receiver brace.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that everything is present and accounted for.



IMPORTANT: All brackets **must** be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts **must** be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one.

- Use flat washers over all slotted holes
- Use lock washers on all fasteners

ROADMASTER Limited Warranty, including One-Year Conditional Warranty Text and Product Registration Card, in Carton.

WARNING


Failure to follow these instructions can result in property damage, personal injury or even death.

- Installation of most mounting brackets requires moderate mechanical aptitude and skills. We strongly recommend professional installation by an experienced installer.
- The installer must read the instructions and use all bolts and parts supplied. Failure to do so could result in loss of the towed vehicle.
- Use Loctite® Red on all bolts used for mounting this bracket.
- Every 3,000 miles, the owner must inspect the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions. The owner must also inspect all mounts and brackets for cracks or other signs of fatigue every 3,000 miles. Failure to do so could result in loss of the towed vehicle.
- The owner must check the vehicle manufacturer's instructions for the proper procedure(s) to prepare the vehicle for towing. Some vehicles must be equipped with a transmission lube pump, an axle disconnect, driveline disconnect or free-wheeling hubs before they can be towed. Failure to properly equip the vehicle will cause severe damage to the transmission.
- If running changes were made by the vehicle manufacturer after this bracket was designed, some bolts or other fasteners in the hardware pack may no longer be the correct size. It is the installer's responsibility to verify that the bracket is securely fastened to the vehicle and fitted with the correct hardware to account for these changes. Failure to securely fasten the bracket could result in loss of the towed vehicle.
- If the towed vehicle has been in an accident, it must be properly repaired before attaching the bracket. Do not install the bracket if any structural frame damage is found. Failure to repair the damage could result in the loss of the towed vehicle.
- Roadmaster manufactures many styles of brackets. If your bracket has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out, resulting in non-warranty damage or personal injury.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or bracket while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system, motorhome and/or towed vehicle.
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. Refer to the cable instructions for proper routing. Failure to leave enough slack in the safety cables, or failure to connect the safety cables frame to frame, will result in the loss of the towed vehicle.
- This bracket is designed for use with ROADMASTER tow bars and ROADMASTER adaptors only. Using this bracket with other brands, without an approved ROADMASTER adaptor, may result in non-warranty damage or injury.
- Do not use this document for custom fabrication, as it may not show all parts or structural components. Custom fabrication or an attempt to copy this bracket design could result in loss of the towed vehicle.
- Upon final installation, the installer must inspect the bracket to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc., or non-warranty damage to the towed vehicle will result.
- This bracket is only warranted for the original installation. Installing a used bracket on another vehicle is not recommended and will void the warranty.




MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



1. **Important:** please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. Now, begin the installation by removing three T30 Torx (head) bolts attaching the upper fascia to the core support (Fig.C).


2. On each side, remove one 8mm (head) screw attaching the fascia to the fender liner (Fig.D).



3. On each side, remove three 8mm (head) screws attaching the fascia to the lower splash shielding and one in the middle (Fig.E).

4. On each side, carefully pull up and out on the fender trim, while releasing from inside the fascia the three clips that are along the forward edge of the trim. Then, continue to pull the trim away from the frame, releasing the two gray clips (Fig.F). Then, remove one T30 Torx bolt attaching the corner of the fascia to the fender (Fig.F). Disconnect the side marker lights, if the vehicle is so equipped.


5. On each side, pull out and forward on the corners of the fascia to remove it, disconnecting the ambient temperature sensor (Fig.G – driver's side) and fog lights, if the vehicle is so equipped.







MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



6. On the passenger side only, pull up and out to release the filler neck. Remove two T30 Torx (head) bolts attaching the top of the washer bottle to the frame (Fig.H). Then, carefully lift the washer bottle out and maneuver the washer bottle around the framing. Secure the bottle away from the frame for now (Fig.I).



7. On the driver's side only, remove two T30 Torx bolts attaching the horn bracket to the bumper core (Fig.J). Remove the 10mm (head) nut attaching the lower horn to the bracket (Fig.K). Reattach the horn to the subframe support using the 10mm nut (Fig.L).



8. On each side, remove two T30 Torx bolts attaching the support bracket to the subframe (Fig.M – passenger side).






MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



9. Place each support bracket in a vise and bend the upper mount so that it is slightly over center as shown in Figure N to allow clearance of the mounting braces. Reinstall each support bracket. On the upper mount, place the supplied 1" x .188 wall x 3/4" pipe spacer between the support bracket and the upper mount. Then, place the 6mm lock washer and 1/4" flat washer over the 6mm x 1.0 x 40mm bolt and bolt through the support bracket, pipe spacer and subframe. On the bottom hole, use one of the T30 Torx bolts you removed in the previous step (Fig.O). Then, on each side, trim the air deflector as shown (Fig.O). It should be trimmed approximately flush with the intercooler once it is trimmed.

10. On each side, remove two 18mm (head) bolts attaching the bumper core to the frame (Fig.P).



11. On the driver's side only, slide the driver's side mounting brace through the aluminum crossmembers. *Note:* use the drawing on page 1 of these instructions for a reference for determining the specific part for each side. Place the 12mm lock washers over the two 12mm x 1.5 x 110mm bolts, and bolt through the mounting brace, through the 1" x 1/4" x .188 wall pipe spacers and then into the frame rail (Fig.Q and Fig.R). *Note:* ensure proper alignment, as the bolts will receive Loctite® Red and will be torqued at the end of these instructions.



12. Repeat step 11 for the passenger side of the vehicle.



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4




Fig.S



Fig.T

13. Now, place the main receiver brace between the two rear mounting braces. On each side, using the two supplied $\frac{1}{2}$ " x $1\frac{1}{4}$ " bolts, bolt through the rear mounting brace and the main receiver brace and finish with a $\frac{1}{2}$ " lock washer and nut (Fig.S).

14. Pull forward and up on the main receiver brace until it is level and square (approximately $2\frac{5}{8}$ " from the top of the main receiver brace to the bottom of the bumper core) (Fig.T). Now, tighten the rear bolts first, and then the front bolts to the bolt torque requirements found at the end of these instructions. *Note:* use Loctite® Red on all nuts and bolts.




Fig.U




Fig.V

15. Remove the foam shock absorption pad (Fig.S). Then, trim a section approximately $5\frac{1}{2}$ " wide and $\frac{1}{2}$ " deep on center to allow clearance for the bolt heads (Fig.U).

16. Use the edges of the center mounting plate to measure up 2" and then over 1" on each side of the plate, and mark for drilling. Drill a $\frac{1}{2}$ " hole level and square through the face of the bumper core (Fig.V) and the main receiver brace and bolt the mounting plate to the back of the bumper core using the two supplied $\frac{1}{2}$ " x $2\frac{1}{2}$ " bolts and $\frac{1}{2}$ " plate washers on the top holes. Finish with $\frac{1}{2}$ " lock washers and nuts (Fig.W). *Note:* ensure the drill is a proper length to avoid drilling through the radiator.

Tighten the bolts to the bolt torque requirements found at the end of these instructions. *Note:* use Loctite® Red on all nuts and bolts.



Fig.W



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



17. Trim the fascia as shown in Figure X, and then replace the shock absorption pad you trimmed in step 15.

18. Reinstall the fascia, reversing steps 1 through 6. *Note:* if the gray plastic fasteners did not originally detach with the trim piece (Fig.Y) then you will need to place it in the slotted hole on the trim before reversing step 4. To accomplish this, pop it out of the fender and slide it back into the slot on the inside of the trim.




19. **Note:** the following four images are for illustration purposes only, as your specific application may be slightly different.

The spring-loaded pin on the removable arm snaps into a notch on the receiver, locking the removable arm into its final towing position. Before inserting each arm into the receiver, verify that the spring is working by ensuring that the spring-loaded pin moves easily back and forth within the barrel when pulled and that it can be pulled flush with the face of the barrel (Fig.Z and Fig.AA).



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 521884-4



20. On each side, insert the removable front bracket arm into the front receiver 90 degrees from its final towing position, depressing the spring-loaded pin against the receiver (Fig.BB). Now, twist back 90 degrees until the spring-loaded pin snaps into place in the notch on the receiver, locking the arm into place in its final towing position (Fig.CC).

Please note: it is the owner's responsibility to ensure the locking of the pins before towing. Otherwise, failure of the towing system will result.

21. Install the tow bar to the mounting bracket according to the manufacturer's instructions.

IMPORTANT!

Safety cables are required by law. When towing, connect safety cables to the safety cable tab shown in Figure DD. Make certain there is adequate slack in the cables to allow a full turning radius; otherwise, damage will result. If necessary, longer cables or cable extensions are available.

Note: if the bracket is so equipped, the holes in the alignment tabs which are welded to the arms and main receiver braces are for padlocks only. Under no circumstances should you bolt the alignment tabs together. Bolting the alignment tabs together may result in non-warranty damage to the bracket.





MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS


KIT# 521884-4

Three options for attaching the wiring plug to the main receiver brace

For six-wire plugs: use the two supplied 3/4" self-tapping screws to attach the electrical plug directly to the rods on the front of the main receiver brace.

For four-wire round plugs: attach to the plug mounting plate and then use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

For four-wire flat plugs: place the plug through the mounting plug plate, and then secure it using the supplied zip tie on the front of the plug (Fig.EE). Use the two supplied 3/4" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.



BOLT TORQUE REQUIREMENTS

STANDARD BOLTS

Thread Size	Grade	Torque
5/16.....	5.....	13 ft./lb.
3/8.....	5.....	23 ft./lb.
7/16.....	5.....	37 ft./lb.
1/2.....	5.....	56 ft./lb.
5/8.....	5.....	150 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
8mm-1.0	8.8	20 ft./lb. 18 ft./lb.
8mm-1.25	8.8	19 ft./lb. 18 ft./lb.
10mm-1.25	8.8	38 ft./lb. 36 ft./lb.
10mm-1.5	8.8	37 ft./lb. 35 ft./lb.

METRIC BOLTS

Thread Size	Grade	Plated / Unplated
12mm-1.25	8.8	70 ft./lb. 65 ft./lb.
12mm-1.5	8.8	66 ft./lb. 61 ft./lb.
12mm-1.75	8.8	65 ft./lb. 60 ft./lb.
14mm-2.0	8.8	104 ft./lb. 97 ft./lb.

All illustrations and specifications contained herein are based on the latest information available at the time of publication approval.
ROADMASTER, INC. reserves the right to make changes at any time without notice in material, specification and models or to discontinue models.