



**ROCK HARD 4X4 JEEP WRANGLER TJ/LJ
1997-2006 FUEL TANK SKID PLATE
PART #: RH-3008
Installation Manual**



Thank you for your purchase! Please read all instructions carefully prior to beginning installation of your Rock Hard 4x4 product.

PACKING LIST:

- 4 - SPACERS (OPTIONAL)**
- 1 - SKID PLATE**

Thank you for your purchase! Whether you bought this Rock Hard 4x4 product from one of our fantastic dealers or our factory direct team, we thank you for your business.

Rock Hard 4x4 is a family owned and operated business. We are headquartered in Saint Paul, Nebraska where we design, fabricate, and produce every single one of our products. Every single part we manufacture is 100% Made in the USA and exclusively in house by the Rock Hard 4x4 team.

We outsource zero processes.

To you, that means the product you are installing is the highest quality and longest lasting component on the market.

To us, that means you've selected a part we've spent years developing. Each Rock Hard 4x4 part has gone through more research and development and evolution than most people realize. While our parts may have the same striking look year after year, subtle revisions and refinements we implement maintain their status as the most durable and easy to install on the market.

We invite you to send us your feedback! Please email, call, write, or catch us on an off road trail near you to share your tales, share comments, and ask questions.

PRO TIP: This installation is much easier if vehicle fuel tank is as empty as possible. On some Jeep TJ's without a body lift – use four optional spacers on 4 front bolts.

1. Unplug electric plug from vehicle fuel tank.
2. Remove fuel hose at tank.
3. Remove vent hose at tank.
4. Remove fuel line from tank.
5. Remove fuel return line from tank.
6. Place floor jack under center of tank to help support it.
7. Remove four nuts at front of tank and four nuts at rear of tank that bolt to frame. Keep all hardware.
8. Lower tank very slowly and remove from under vehicle.
9. Remove nuts from straps.
10. Remove tank from factory skid support.
11. Install straps into new skid.
12. Drop tank into skid plate and bolt straps down.
13. Reinstall tank in vehicle in reverse order you removed it.
14. If track bar hits skid, adjust tank to rear as far as slots will allow.

CONGRATULATIONS! Now go wheel your rig with a whole new level of confidence and capability.