

[Table Of Contents](#)

Preface

Acknowledgments

What is a Workbench® Book?

Introduction

Chapter 1: Systems Overview

Fuel System
Oiling System
Cooling System
Cylinder Heads
Exhaust System
Electrical System
Glossary of Terms

Chapter 2: 7.3-Liter Removal and Disassembly

Air Inlet System
Front Belt Drive Accessories and Radiator
Final Accessories
Turbocharger
Engine Removal
Begin Disassembly
Fuel System
Fuel Injectors
Driver-Side Cylinder Head
Coolant System
HPOP System
Passenger-Side Cylinder Head
Transmission-Related Accessories
Remaining External Accessories
Reciprocating Assembly

Chapter 3: 6.0-Liter Removal and Disassembly

Interior Lights
Front Drive Accessories and Radiator
Remaining Accessories
Remove Transmission (Automatic)
Remove Engine
Transmission Accessories
Injectors and Glow Plugs

Cylinder Heads
Disassemble Reciprocating Assembly

Chapter 4: Inspection and Machine Shop Work

Chapter 5: Engine Reassembly

Crankshaft
Pistons
Camshaft and Lifters
Cylinder Heads
High-Pressure Oil Pump (HPOP)
Oiling System

Chapter 6: Installation and Break-In

7.3-Liter Engine
Transmission
Engine
Fuel and Oil Systems
Front Drive and Cooling Systems
Exhaust System
Re-Service Engine
6.0-Liter Engine
Turbo System
Oil, Fuel and Glow Plug Systems
Finalize Accessory Installations
Chapter 7: Performance Upgrades
Cold-Air Kits
Exhaust Systems
Gauges
Aftermarket Dampeners
Computer Reprogrammers
Turbos and Intercoolers
Injectors and HPOPs
Flywheels
Turbo Timers

Appendix

Cylinder Head Torque Sequence
Flywheel Torque Sequence
Intake Manifold Fastener Torque Sequence
Cylinder Location
Basic Specifications
Power Stroke Capacities
Fault Codes

Source Guide