

# **SUPERBones**



3 bikes






## **Optional Accessories**








## Preparing for installation



Step 1: Reference fit guide, to determine strap placement and lower foot position. \*Rack can not be mounted without first confirming compatibility. If strap/hook placement needs adjustment, see instruction in Appendix A.



Step 2: Clean surface of vehicle which will be in contact with rack.



Step 3: Adjust the upper legs.


3a Lift "lock" lever to release upper leg


3b Rotate leg into general position to place on car

3c Close lever

3d Repeat with 2nd leg

## Figure 1 - General Placement on Car







Step 4: Adjust the Arms.

- 4a Lift "lock" lever to release arms
- 4b Rotate arm into general position
- 4c Close lever
- 4d Repeat with 2nd arm


### **Install Rack on Vehicle**



Step 5: Place rack onto vehicle. Use fit guide information to properly position lower feet on bumper, trunk face or license plate.



Step 6: Re-adjust upper legs so rack spline is directly above vehicle bumper.




Step 7: Attach top hooks.

7a push and hold "free" lever to extend straps.

7b Secure hooks in hinge line of vehicle.
7c Push and hold "free" lever to take out strap slack.
\*\*See fit guide for hatch hugger compatibility.

Note: Do not open truck with rack installed on car.




Step 8: Attach lower hooks.

8a Push and hold "free" lever to extend straps.


8b Secure lower hook into trunk lip and ensure that strap runs through the lower foot groove.

8c Push and hold "free" lever to take out strap slack.




Step 9: Tighten all straps by opening and closing "free" lever to activate ratchet mechanism. Tighten upper straps first and finish with lower straps.


# **Load Bikes**




Step 1: Fold up anti-sways.



Step 2: Place bikes on rack with heaviest/biggest bike closest to vehicle. Orient bike to align seat tube with anti-sway.




Step 3: Tighten hold down straps over bike's top tube.




Step 4: If bike spacing adjustment is needed rotate anti-sway strap.


4a Tighten anti-sway strap onto seat post tube.



Step 5: Once bikes are loaded recheck strap tension and tighten upper, and lower straps as necessary.




Step 6: Lock rack to vehicle. 6a To lock upper and lower legs, insert key and turn to locked position.




Step 7: Lock bike to rack.
7a To lock bike to rack, wrap locking cable over bike's top tube and insert into lock slot.

7b Insert key and turn to locked position.

## Remove Rack




Step 1: Unlock upper and lower legs.




Step 2: Remove upper and lower hooks.

2a Push and hold "free" lever on upper leg to release strap tension.


2b Repeat on lower leg.




Step 3: Retract strap. Guide strap into leg.




Step 4: Fold flat for storage.




Step 1: Pull back sleeve covering hook attachment.




Step 2: Pinch strap and slide through opening on hook to remove hook.




Step 3: Remove sleeve.



Step 4: Feed strap through leg to desired position.





Step 5: Pull sleeve over hook attachment strap and re-attach hook.

Technical Specifications Bike carrier weight: 19lbs/9kg Permitted load capacity: max 105lbs/48kg

Max bike weight: 35lbs/16kg

#### CAUTIONS:

- All requirements for compatibility/fit as stated in the current Saris vehicle/carrier compatibility guide must be followed. (Available at any Saris dealer).
- Read and follow instructions carefully. Save owner's manual for future reference or parts information. Ensure that any other users of the bicycle carrier are familiar with their content.
- It's the end users responsibility to ensure that use of this product meets all local and state laws.
- When cleaning vehicle and rack, use only water soluble cleaners. Do not take rack through car wash.
- Make sure bike tires are not directly behind exhaust pipe.
- Do not mount to any type of trailer, towed vehicle or RV.
- · Prior to usage on the road, remove all loose parts from bicycle, including (but not limited to) child seat, basket, lock, light, pump, etc.
- This carrier is not recommended for off-road use or for use at speed exceeding 70 mph (113 km/h).
- The handling characteristics of a vehicle will change when a rear bicycles carrier is fitted and especially when it is loaded (in particular crosswind sensitivity, handling on bends and braking). Driving techniques should be altered to allow for these changes, reduce speed, especially on bends and allowing for longer braking distances.
- The vehicle's total length increases when the bike carrier is attached. The bikes themselves may increase the vehicle's total width and height. Take care when reversing and/or entering garages or ferries, etc.
- · Do not open rear deck (trunk) with carrier installed.
- · Remove carrier from vehicle when not in use.
- Rear window wipers may not be usable while carrier is attached to vehicle.
- . This carrier is constructed to carry standard-bike-frames. It is not intended for use with tandem or recumbent bicycles.
- Never place more than three bicycles (maximum weight 105lbs/48kg) on carrier. Secure properly and adjust for even load distribution, loading the heaviest/biggest bike first and closest to the vehicle.
- · Replace any mounting strap at the first sign of wear.
- · Upper-hook straps must be parallel with the rear leg to prevent shifting.
- · Rack spline is directly above with vehicle bumper.
- No part of carrier, including straps, should ever come in contact with spoiler.
- To prevent potential damage, secure the front tires of bicycles (part number 3033 recommended).
- Tighten straps and buckles regularly during the journey.
- Saris absolves itself of responsibility for any personal injuries or consequential damage to property or wealth caused by incorrect fitting or use.

#### Warning and Disclaimer:

This carrier has been designed to carry bicycles on specific vehicles. Before installation, user must read and follow current Saris Fit Guide (available through Saris dealer) recommendations and enclosed instructions. Fit recommendations are based on vehicle's standard features; optional features may affect the fit recommendations. User must attach carrier correctly to the vehicle, check its attachment before each use, and inspect carrier parts for wear. Carrier's attachment to the vehicle is critical and beyond the control of the manufacturer. Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this carrier.