



SEALFLEX ELASTOMER BEARING

***PRESS IN BUSHING; "G" BODY TRAILING ARM STYLE
(FITS MOST STYLES)***

- 1.) REMOVE STOCK BUSHING CAREFULLY***
- 2.) PRESS SEALFLEX BUSHING INTO ARM – NOTE;
FOR RETENTION IN STOCK ARM, SMALL (1/8")
"TACK" WELDS MAY BE REQUIRED DUE TO ARM
DISTORTION WHILE REMOVING STOCK BUSHINGS
THE BEST LOCATION IS ON THE LARGE DIAMETER
OF THE BUSHING ON THE FLANGE. CARE MUST BE
EXERCISED TO MAKE SURE ELASTOMER IS NOT
BURNED!***
- 3.) THE "THRU BOLT" WHEN INSTALLED, SHOULD BE
TIGHTENED JUST ENOUGH SO THAT THE BUSHING
ENDS JUST TOUCH THE MOUNT. THEN "BACK OFF"
THE NUT ½ TO ¾ OF A TURN SO THAT PART
ROTATES FREELY WITH NO "SIDE PLAY". THE NUT
USED SHOULD BE A SELF-LOCKING TYPE SUCH AS
"NYLOCK"***