


SPECTRE®

Performance

Intake Installation Instructions **P/N 10268 (red filter) - P/N 10268B (blue filter)** **P/N 10268K (black filter)**

Year/Make/Model/Engine
2009-2014 Toyota Corolla-S 1.8L



Parts List

- 1 - Air filter
- 1 - Intake tube
- 1 - Heat shield
- 1 - 5/8" Breather hose- 13"
- 1 - Rubber seal- 56"
- 1 - Rubber seal- 17"
- 2 - Machine screws
- 5 - 6mm Hex bolts
- 2 - 6mm Lock nuts
- 5 - 6mm Washers
- 4 - Fender washers
- 3 - Lock washers
- 1 - "L" Bracket
- 2 - "C" Brackets
- 1 - 2.5"- 2.75" coupler
- 2 - 1" Hose clamps
- 1 - 2.5" Hose clamp
- 1 - 2.75" Hose clamp
- 1 - 3" Hose Clamp


Tools Required:

- Phillips screwdriver
- Standard screwdriver
- 5/16" nut driver
- 10mm socket
- 12mm socket
- 6" extension
- Ratchet
- 10mm combination wrench

P/N HPR9888 (red filter)
P/N HPR9888B (blue filter)
P/N HPR9888K (black filter)


Step 1

Safety first! Before you begin the installation, make sure that the vehicle is in park (or neutral for a manual transmission) with the parking brake set. Disconnect the negative battery terminal and verify that all components that are listed are present. Note: This kit was designed and tested on a stock engine without any custom tuning done to the engine computer. Removing the battery cable may erase the programmed radio stations. The anti-theft code will need to be entered into some radios after the battery cable is connected. The anti-theft code can typically be found in the owner's manual or at your local dealership.




Step 2

Pull up firmly to remove the plastic cover from the engine and set it aside.




Step 3

Disconnect the crank case vent hose from the valve cover nipple and the intake tube.




Step 4

Disconnect the Mass Air Flow Sensor (MAFS) electrical connector then unhook MAFS wiring harness from the upper air box.




Step 5

Loosen the hose clamp at the throttle body. Unclip the upper air box retaining clips and then remove the upper air box and intake tube as an assembly.




Step 6

Unclip the wiring harness from the back of the air box. Remove the three air box bolts then and remove the lower air box housing from the vehicle.



Step 7


Install the two supplied "C" heat shield mounting brackets on the factory air box mounting bracket in the two holes closest to the engine. Secure the brackets with 2 supplied hex bolt, lock washer and flat washer. Position the "C" brackets facing opposite directions (one facing left and one facing right) from each other.




Step 8
Remove the bolt which secures the wiring harness to the engine. This will be used later in Step 11.




Step 9
Install the supplied long piece of rubber seal on the outside edge of the heat shield. Install the short piece of rubber seal around the inner edge of the hole in the heat shield.




Step 10
Install the heat shield into the vehicle. Once the slots on the heat shield are lined up with the brackets from Step 7, fasten securely in place with the hardware provided.



Step 11
Install the "L" shaped bracket and fasten it securely in place using the hardware removed on Step 8. Install the reducer coupler on the throttle body and fasten securely. Install the second clamp but do not tighten at this time.




Step 12
Remove the two screws that secure the MAFS to the factory air box and remove the MAFS.




Step 13
Install the MAFS into the Spectre Performance intake tube and secure with the supplied screws.




Step 14
Install the supplied crank case vent hose on the vent tube.




Step 15
Install the Spectre Performance intake tube through the heat shield and then into the coupler on the throttle body. Align the tube with the "L" bracket installed in Step 11 and install the supplied hardware. Secure the intake tube on the throttle body with the hose clamp.




Step 16
Install the crank case vent hose to the valve cover fitting and securely fasten it with the supplied clamp. You may need to trim the supplied hose down for proper fitment while making sure there are no kinks.



Step 17
Route the MAFS wire harness through the heat shield opening next to the intake tube and then connect the electrical connector to the MAFS.



Step 18
Install the HPR air filter on the intake tube and secure with the supplied hose clamp.



Step 19
Install the engine cover. Make sure that all clamps and hardware are fully tightened. Reconnect the battery cable, start the vehicle and let it warm up. Shut off and inspect the installation once more for any loose clamps, wires, or hardware. Test drive & enjoy! Your installation is now complete. Periodically check all clamps and brackets.