

SPECTRE®

Performance

Intake Installation Instructions

P/N 9009 (red filter) - P/N 9009B (blue filter)

P/N 9009K (black filter)

Year/Make/Model/Engine

2005-2011 Toyota Tacoma 4.0L

2003-2008 Toyota 4 Runner 4.0L

2007-2009 Toyota FJ Cruiser 4.0L




Parts List

- 1- Air box Lid
- 1- Gasket support
- 1- Filter
- 1- Heat shield
- 1- 4" 30° coupler
- 1- Filter funnel
- 1- Rubber seal
- 2- Hex bolts, M8x16
- 2- Washers, M8
- 2- 4" Hose clamps
- 1- C.A.R.B. sticker

Tools Required:


- 5/16" or 8mm nut driver
- Ratchet
- 10mm socket
- 12mm socket
- 13mm socket
- Socket extension

P/N HPR9892 (red filter)
P/N HPR9892B (blue filter)
P/N HPR9892K (black filter)




Step 1

Safety first! Before you begin the installation, make sure that the vehicle is in park (or neutral for a manual transmission) with the parking brake set. Disconnect the negative battery terminal and verify that all components that are listed are present. Note: This kit was designed and tested on a stock engine without any custom tuning done to the engine computer. Removing the battery cable may erase the programmed radio stations. The anti-theft code will need to be entered into some radios after the battery cable is connected. The anti-theft code can typically be found in the owner's manual or at your local dealership.




Step 2

Remove the two screws securing the resonator.




Step 3

Unclip the air box lid from the vehicle and remove the lid assembly from the vehicle.




Step 4

Remove the screw that secures the power steering reservoir to the vehicle. The screw will be reused in Step 9.




Step 5

Remove the bolt that secures the A/C line bracket.



Step 6

Reposition the A/C line bracket to line up with the hole on the power steering reservoir. Do not fasten it right now this will be done in a later step. You may need to loosen the nut on the rubber isolation mount allowing you to turn the bracket. If so make sure you tighten the nut back up after positioning.



Step 7
Remove the factory seal from the perimeter of the filter.




Step 8
Install the seal on the gasket support ring.




Step 9
Install the gasket inside the base of the air box. Then install the air box cover into the vehicle making sure to use the factory retaining clips to hold the cover in place.




Step 10
Install the rubber bulb seal.



Step 11
Install the heat shield into the vehicle. Place the one tab between the power steering reservoir and the inner fender and use the screw removed in Step 7. Secure the heat shield in the two other locations with the provided hardware.



Step 12
Install the supplied flex coupler and place the velocity stack adapter in the heat shield making sure the funnel and coupler is pushed completely against the heat shield. Take note of the orientation of the funnel, this may be rotated slightly once the filter is installed in the vehicle. Once in the desired location fasten it securely in place.



Step 13
Install the filter on the velocity stack adapter and fasten it securely. If required rotate the velocity adapter so the filter will fit without any fitment issues.



Step 14

Make sure that all clamps and hardware are fully tightened. Reconnect the battery cable, start the vehicle and let it warm up. Shut off and inspect the installation once more for any loose clamps, wires, or hardware. Test drive & enjoy! Your installation is now complete. Periodically check all clamps and brackets.

Step 15

The C.A.R.B. exemption sticker, (attached), must be visible under the hood, so the emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

SPECTRE[®]
Performance