

SPECTRE®

Performance

Intake Installation Instructions P/N 9051 (red filter) - P/N 9051B (blue filter) P/N 9051K (black filter)

Year/Make/Model/Engine

1991-2001 Jeep Cherokee 4.0L




Parts List

- 1- Intake tube
- 1- Heat shield
- 1- Air filter
- 1- 6" Hose clamp
- 1- 3" 90° coupler
- 1- Coupler sleeve
- 1- 3" Flex coupler
- 1- Velocity stack adapter
- 1- Edge trim
- 4- 3" Hose clamps
- 2- Mini hose clamps
- 1- 5/8" Hose
- 1- M8 bolt
- 1- M8 washer

Tools Required:


- 5/16" or 8mm Nut driver
- Flat blade screwdriver
- 10mm socket
- 13mm socket
- Extension
- Ratchet

- P/N HPR9606 (red filter)
- P/N HPR9606B (blue filter)
- P/N HPR9606K (black filter)




Step 1

Safety first! Before you begin the installation, make sure that the vehicle is in park (or neutral for a manual transmission) with the parking brake set. Disconnect the negative battery terminal and verify that all components that are listed are present. Note: This kit was designed and tested on a stock engine without any custom tuning done to the engine computer. Removing the battery cable may erase the programmed radio stations. The anti-theft code will need to be entered into some radios after the battery cable is connected. The anti-theft code can typically be found in the owner's manual or at your local dealership.




Step 2

Loosen the clamp at the throttle body. Remove the crank case vent hose from the fitting on the valve cover.



Step 3

Unclip the three hold down clips on the air box lid. Remove the intake tube and air box lid assembly, and the air filter from the vehicle.



Step 4

Remove the two bolts and one nut in the bottom of the air box and remove air box from vehicle. The nut will be reused in a later step.




Step 5

Install the rubber bulb seal. Place the velocity stack adapter in the heat shield and install the supplied flex coupler making sure the coupler is pushed completely against the heat shield. Once the adapter and coupler are tight against the heat shield, tighten the clamp.




Step 6

Install the filter and securely fasten to the velocity stack adaptor.




Step 7


Remove the bolt on the core support and this bolt will be reused in the next step.




Step 8
Install the heat shield into the vehicle as shown by reusing the hardware from Step 4 and Step 7.




Step 9
Install the coupler sleeve onto the throttle body.



Step 10
Install the intake tube into the flex coupler and then install the 90° coupler to the intake tube and then position it onto the throttle body as shown. Once in desired position fasten it securely in place.



Step 11
Install the supplied crank case vent hose and fasten it securely in place.



Step 12
Make sure that all clamps and hardware are fully tightened. Reconnect the battery cable, start the vehicle and let it warm up. Shut off and inspect the installation once more for any loose clamps, wires, or hardware. Test drive & enjoy! Your installation is now complete. Periodically check all clamps and brackets.