



1




- Remove the end cap 1 and the feet 2 from each bar on one side of the rack.

2




- Loosen the screws 3. Install the two lengthways tubes according to the diagram.

3




- Put the feet 2 and the end caps 1 back on the rack.

4




- Using the included fit chart, adjust foot positions to the numbers for your vehicle. Use "Front" dimensions for front bar and "Rear" for rear bar. Tighten feet 4 to 6Nm / 53 in-lbs.

5




- Put the clamp plate bracket in position on the lengthways tube.

6




- Remove the clamp plates from the feet and assemble them loosely on the brackets.

7




- Adjust bracket positions according to distance B indicated for your vehicle. Tighten fixing bolt 5 to 5 Nm / 44 in-lbs.

8



- Position the rack on your vehicle according to distance A indicated for your vehicle.

9



- Tighten bolts 3 and 6 to 5 Nm / 44 in-lbs. Be sure the lengthways tubes are flush against the feet. Check that all fittings are secure and correctly positioned.