


PARTS INCLUDED

description	part number	qty.
foam blocks	ABR527R	4
15 foot blue straps	ABR702	2
aluminum bar	853-7710	2
metal bumper hooks	853-7711	4
bow/stern black tie-down straps	ABR704	2 pair
9 foot red straps	ABR700	2


WARNINGS / LIMITATIONS •

- Do NOT use the aluminum bars for carrying any other load than the intended use of kayaks, surfboards or stand-up paddleboards as instructed.
- You are responsible for attaching the racks and accessories to your vehicle securely and periodically inspecting the product for wear and damage. Improper attachment could result in an automobile accident and serious injury.
- SportRack is not responsible for damage to your gear or vehicle. For heavier loads consider purchasing a full rack system.
- After driving 5 miles, stop to ensure straps/ropes are still tight. Limit transport distance to 250 miles.
- Do not place blocks on sunroofs or spoilers.
- Be sure to cover an exposed kayak cockpit on rainy days.


1




- Clean the bottom anti-skid surface of the foam blocks and top of the vehicle prior to loading kayaks, surfboards, or stand-up paddleboards.

2**A**


- The foam blocks should be slid onto the aluminum bar provided. Two blocks per bar with the foam sloping toward the center of the bar.

B


- Run a blue strap through the center of each bar provided.

3


- Place foam blocks and both aluminum bars on top of vehicle roof with the rubber anti-skid surface facing down. Blocks should be placed close to the front windshield and rear window. Secure foam and bars to vehicle by opening vehicle doors and pulling both ends of one strap into the vehicle. Run one end of strap through the buckle and tighten firmly on inside of vehicle. Repeat with second strap most likely using other set of doors. If your car has siderails, you may tie strap(s) to it instead.

4


- Load the kayak, surfboard or stand-up paddleboards onto the foam blocks on top of the vehicle. The kayak cockpit should face up and the weight should be evenly distributed across the roof. The foam blocks may be slid inward or outward on the aluminum bar depending on the width of the kayak, surfboard or stand-up paddleboard. To load a surfboard or stand-up paddleboard, place the board on the foam blocks upside down with the fin preferably toward the rear of the vehicle.

5

- Place both red straps across top of kayak, surfboard or stand-up paddleboard not directly across kayak cockpit. Secure kayak, surfboard or stand-up paddleboard to aluminum bar by looping red strap over kayak, surfboard or stand-up paddleboard and around or through aluminum bar.

6

- If the surfboard or stand-up paddleboard is wider than the maximum width of the bar and blocks (30") then please loop the strap that goes over the board under the strap that feeds through the vehicle as shown.

7

- Secure front and rear of the kayak with the rope bow/stern tie-down and bumper hooks provided. Avoid running safety lines across sharp edges or near the exhaust. Each black strap has a looped end which should be attached to a bumper hook. The other ends should be looped through the kayak handles, buckled and tightened.

NOTE: Check all straps and tie-downs for tightness regularly.

8

SUGGESTIONS

- Twisting the straps a few turns will help prevent strap vibration and noise at high speeds.
- To prevent vehicle damage with a boat on top, you may need to remove antenna from roof and use caution when opening hatchbacks.