

KNOCK SENSOR INSTALLATION INSTRUCTIONS

The Knock Sensor in this package may be a different design than what is currently on the vehicle. This will not affect performance.

DESCRIPTION

1. Install the Boss to engine block using M12 x 1.25 thread. Tightening torque is 13 ± 1 N.m. The Boss has 24mm HEX.
2. Install the Knock Sensor on the Boss. Direction of Knock Sensor is universal to allow installation of wiring, and to avoid interference with other parts. Align the Knock Sensor to the wiring harness before tightening the retaining nut.
3. Apply thread lock adhesive (Loctite 271) to the exposed threads of the boss, above the Knock Sensor.

Caution: Do not apply adhesive to the Boss, below the exposed area.

4. Install M8 Nut and torque 13 ± 1 N.m. Wipe off any extra Loctite 271. The Loctite 271 will dry in approximately 3 minutes.

