



**Connecting Street Scene Signal® Mirrors  
Instructions For Part Numbers**

<b>950-15210</b>	<b>950-17240</b>	<b>950-26220</b>
<b>950-15220</b>	<b>950-18220</b>	<b>950-27220</b>
<b>950-15226</b>	<b>950-20220</b>	<b>950-27226</b>
<b>950-15240</b>	<b>950-25210</b>	<b>950-27240</b>
<b>950-17245</b>	<b>950-25220</b>	<b>950-27242</b>
<b>950-17220</b>	<b>950-25226</b>	<b>950-27245</b>
<b>950-17226</b>	<b>950-25240</b>	<b>950-28220</b>

1. Install Street Scene Signal® Mirrors assemblies to doors following mirror installation instructions.
2. Before beginning electrical hook-up check the operation of turn signals in the front and rear of vehicle. If any problems exist, repair before installing Street Scene Signal® Mirrors.
3. Run the Red / Black wire on the mirror into the door. Pull the rubber boot between the door and frame. Guide the wire harness through the door and out the hole located by the boot. Remove any slack.
4. Remove the door sill plate and remove the kick panels.
5. Pass the wire harness through the rubber boot between the door and the door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side. Run the wire across the dash to beneath the steering column. It will be necessary to remove lower dash panels to do this.
8. The vehicles electrical wiring is located beneath the steering column. NOTE: On some vehicles it may be necessary to remove a metal plate beneath the steering column.
9. Locate the solid LIGHT BLUE wire on the top of the wiring block. Turn the ignition key so that electrical power is on and activate the driver side turn signal. Probe the wire with the wire tester to verify that flashing turn signal is present. Label that wire as " Drivers Side Turn". Locate the solid DARK BLUE wire on the top of the wiring block. Activate the passenger side turn signal and probe the wire with the wire tester to verify that flashing turn signal power is present. Label that wire as " Passenger Side Turn".
10. Make sure the harness are routed securely under the dash and enough slack is left for splicing. When splicing do not cut any wires. Use the quick splice connectors provided.
11. Splice the RED wire from the driver side harness into the LIGHT BLUE wire previously labeled " Driver Side Turn ".
12. Splice the RED wire from the passenger side harness into the DARK BLUE wire previously labeled " Drivers Side Turn ".
13. Strip and twist together the ends of the black wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal frame work of the vehicle.
14. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working. Replace all of the lower dash panels.