



STREET SCENE EQUIPMENT, INC.

CONNECTING STREET SCENE SIGNAL® MIRRORS

| INSTRUCTIONS FOR PART NUMBERS | | |
|-------------------------------|-----------|-----------|
| 950-15710 | 950-17720 | 950-20720 |
| 950-15720 | 950-17726 | 950-27726 |
| 950-15726 | 950-17730 | |
| 950-15730 | 950-18720 | |

1. Install Street Scene Signal® Mirror assemblies to doors following mirror installation instruction.
2. Before beginning electrical hook - up check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installing Street Scene Signal® Mirrors.
3. Run the Black / Red wire from the mirror into the door and into the rubber boot. Pull the rubber boot out between the door and door frame. Pass the wire harness into the vehicle by going through the opening located by the rubber boot. Run the wire to the left of the steering column. Do the same on the other side of truck. Re-install rubber boots.
4. The electrical wiring for the turn aignal switch is located under the dash just below and left of the steering column. Locate the **GREEN WITH WHITE STRIPE** wire from within the wire bundle. Turn the ignition key so that the electrical power is on and activate the driver side turn signal. Probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Driver Side Turn**". Locate the **WHITE WITH BLUE STRIPE** wire withing the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal power is present. Label that wire as "**Passenger Side Turn**".
5. Make sure the harnesses are routed securely under the dash and enough slack is left for splicing.
6. Splice the **RED** wire from the passenger side harness into the **WHITE WITH BLUE STRIPE** wire previously labeled "**Passenger Side Turn**". Do not cut any wires when splicing.
7. Splice the **RED** wire from the driver side harness into the "**GREEN WITH WHITE STRIPE**" wire previously labeled "**Drivers Side Turn**".
8. Strip andf twist together the ends of the black wires from each harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle. A good ground location is located on the bare metal plate behind the hood release lever.
9. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working.



STREET SCENE EQUIPMENT, INC.

Connecting Street Scene Heated Mirror Conversion Kit

| Instructions For Part Numbers: | | |
|--------------------------------|-----------|--|
| 950-16720 | 950-19720 | |
| 950-16726 | 950-20720 | |
| 950-17720 | 950-27726 | |

SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. **Do not mix up**

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel. Drill a 1/2" diameter hole and insert the switch from the front side and install the nut from the backside and tighten.

NOTE: LOCATION OF WIRES ON SWITCH

Top Of Switch: (Marked "Earth") Black wire from four foot power connecting harness.

Center Of Switch: (Marked "Load") Red wires from right & left mirror heaters.

Bottom Of Switch: (Marked "Supply") Red wire from four foot power connecting harness.

Locate a switched 12 volt power supply at the fuse panel (Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. DO NOT connect to a constant 12 volt power supply.

3. Run the **Red / Black** wire on the mirror into the door and into the rubber boot. Pull the rubber boot out between the door and door frame. Pass the wire harness into the vehicle by going through the opening vacated by the rubber boot. Run the wire to the right of the steering column. Do the same on the other side of truck. Re-install rubber boots.
5. Pass the wire harness through the rubber boot between the door and the door frame.
6. Guide the wire harness through the door frame and into the vehicle.
7. Do the same on the passenger side. Run the wire across the dash to the left side of the steering column.
8. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the " **One to Two** " connector.
9. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.