



STREET SCENE EQUIPMENT, INC.

CONNECTING STREET SCENE SIGNAL® MIRRORS

INSTRUCTIONS FOR PART NUMBERS		
950-15810	950-17820	950-27820
950-15820	950-18820	
950-15825	950-20820	

1. Install Street Scene Signal® Mirrors to doors following installation instructions.
2. Before beginning electrical hook-up, check the operation of turn signals in the front and rear of vehicle. If any problem exist, repair before installing Street Scene Signal® Mirrors.
3. Remove the door sill plates and kick panels.
4. Run the **RED / BLACK** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame.
6. Do the same on the passenger side. Run the wire across the dash past the steering column to the extreme left side of dash.
7. The electrical wiring for the Ford Ranger is located along the corner of the door frame. Roll over part of the carpeting along the door frame to expose the electrical wiring. Guide the wire harness from mirrors down to the wire bundle.
8. Locate the **GREEN WITH ORANGE STRIPE** wire from within the wire bundle. Turn the ignition key so that electrical power is on and activate the driver's side turn signal. Probe the wire with a test light to verify that flashing turn signal power is present. Label that wire as "**DRIVER'S SIDE TURN**".
9. Locate the **ORANGE WITH BLUE STRIPE** wire from within the wire bundle. Activate the passenger side turn signal and probe the wire with the test light to verify that flashing turn signal is present. Label that wire as "**PASSENGER SIDE TURN**".
10. Make sure the harnesses are routed securely to the vehicles wire bundle and enough slack is left for splicing.
11. Splice the **RED** wire from the driver's side harness into the **GREEN WITH ORANGE STRIPE** wire previously labeled "**DRIVER'S SIDE TURN**".
12. Splice the **RED** wire from the passenger side harness into the **ORANGE WITH BLUE STRIPE** wire previously labeled "**PASSENGER SIDE TURN**". When splicing do not cut any wires. Use the quick splice connectors provided.
13. Strip and twist together the ends of the **BLACK** wires from both harness. Crimp them together in the supplied ring connector and ground to a suitable nearby location on the metal framework of the vehicle.
14. Activate each turn signal to verify that the Street Scene Signal® Mirrors are working properly.
15. Replace all trim pieces removed.



Connecting Street Scene Heated Mirror Conversion Kit

Instructions For Part Numbers:		
950-16820	950-19820	950-27820
950-17820	950-20820	

SPECIAL NOTE:

If you are installing Street Scene Mirrors with Signal option, the wiring for the heaters will have a push on terminal and a ring connector on. The wires for the signal system will have no connectors on them. Do not mix up

1. Install Street Scene Heated Mirrors following mirror installation instructions.
2. Mount the switch in a suitable location. A good place is on the lower dash panel or below the headlight switch on the early models. Drill a 1/2" diameter hole and insert the switch from the front side and insert the nut from the backside and tighten.

NOTE: LOCATION OF WIRES ON SWITCH

Top Of Switch: (Marked "Earth") Black wire from four foot power connecting harness.

Center Of Switch: (Marked "Load") Red wires from right & left mirror heaters.

Bottom Of Switch: (Marked "Supply") Red wire from four foot power connecting harness.

Locate a switched 12 volt power supply at the fuse panel (Power goes off when ignition switch is in the " off " position). Using the blue quick splice connector supplied, crimp the Red wire from the switch harness to the wire found at the fuse block. DO NOT connect to a constant 12 volt power supply.

3. Remove the door sill plates and kick panels.
4. Run the **Red / Black** wire on the mirror into the door. Pull out the rubber boot from the door and door frame. Guide the wire harness out of the hole vacated by the rubber boot.
5. Pull the rubber boot out from the door frame. Guide the wire through the rubber boot and into the vehicle. Replace the rubber boot between the door and door frame. Do the same on the passenger side. Run the wire across the dash past the steering column to the extreme left side of dash.
6. Connect the **RED** wire from the right and left wire harness to the center pin on the switch using the "**One to Two**" connector.
7. Attach the **BLACK** wires with the ring connectors to a suitable nearby ground location on the metal framework on the vehicle.