


SumoSprings Front

Suspension Enhancement
GM 2500/3500 HD [2011- present]
SumoSprings Part# SSF-202-47



Driver Side (Passenger side similar)



SSF-202-47 Installation
(actual product material is black)



Front SumoSprings
SSF-202-47 uninstalled

OEM bumpstop



Installation Instructions

- 1) Park vehicle on level hard surface. Engage emergency brake. Place blocks in front and behind rear wheels to prevent rolling. Observe all safety precautions and wear safety glasses.
- 2) Raise front of vehicle allowing the axle to hang freely. Support the frame using safety jack stands.
- 3) Remove the two existing factory jounces in a twist and pull motion and set aside in the event that the SumoSprings are ever removed.
- 4) Insert the two replacement SumoSprings into the factory bump-stop receptacles in a twist and push motion.
- 5) Repeat steps three through four on the other side of the vehicle.
- 6) Jack up vehicle, remove safety jack stands.
- 7) Carefully lower vehicle to the hard surface. Remove the blocks in front and back of the rear wheels.
- 8) Release emergency brake.
- 9) Fill out warranty card and send to SuperSprings. The warranty card is on the reverse side of this page.

Tool List

- *Floor Jack* 1
- *Jack Stands* 2
- *Wheel Blocks* 4

Parts List

- *SumoSprings #SSF-202-47* 4

Important Notice.

- 1) For easy installation please read instructions completely first and have all necessary tools available.
- 2) We recommend that this installation be done by a professional or persons with sound mechanical knowledge.
- 3) SumoSprings are designed to work with the original factory [springs](#) only.
- 4) These instructions are meant as a guide for the installation of SumoSprings. SuperSprings International assumes no liability for the actual installation process. Installers should apply common automotive safety practices when raising, lowering and working on vehicles.
- 5) SumoSprings are designed to enhance the vehicles load carrying performance and road handling however it does not authorize (or recommend) loading beyond the manufacturer's GVWR specifications.

To prevent damage to the vehicle and to ensure safety, do not exceed the maximum load recommended by the vehicles manufacturer (GVWR).