

# **SumoSprings** **Front**

Suspension Enhancement

Mercedes Sprinter 2500 4x4 [2015 ~ present]


SumoSprings Part# SSF-327-47



SSF-327-47



OE bumpstop



SSF-327-47 Installed

# **Installation Instructions**

- 1) Park vehicle on level hard surface. Engage emergency brake. Place blocks in front and behind rear wheels to prevent rolling. Observe all safety precautions and wear safety glasses.
- 2) Raise front of vehicle leaving a small amount of preload on the suspension. Support the frame using safety jack stands.
- 3) Remove factory bump stop from its mounting bracket.
- 4) Using the nut and washer provided, install the SumoSpring onto the factory mounting bracket. Ensure the stud is inserted into the same hole that the factory bump stop was removed from (upper hole). Tighten securely until the top lock feature is fully engaged.
- 5) Repeat steps three and four on the other side of the vehicle.
- 6) Jack up vehicle, remove safety jack stands.
- 7) Carefully lower vehicle to the hard surface. Remove the blocks in front and back of the rear wheels.
- 8) Release emergency brake.
- 9) Fill out warranty card and send to SuperSprings. The warranty card is on the reverse side of this page.

## **Tool List**

- 13mm Wrench 1
- Jack 1
- Jack Stands 1
- Wheel Blocks 4

## **Parts List**

- SumoSprings 2
- 8mm toplock nuts 2
- 8mm washers 2

## **Important Notice.**

- 1) For easy installation please read instructions completely first and have all necessary tools available.
- 2) We recommend that this installation be done by a professional or persons with sound mechanical knowledge.
- 3) SumoSprings are designed to work with the original factory springs only.
- 4) These instructions are meant as a guide for the installation of SumoSprings. SuperSprings International assumes no liability for the actual installation process. Installers should apply common automotive safety practices when raising, lowering and working on vehicles.
- 5) SumoSprings are designed to enhance the vehicles load carrying performance and road handling however it does not authorize (or recommend) loading beyond the manufacturer's GVWR specifications.

***To prevent damage to the vehicle and to ensure safety, do not exceed the maximum load recommended by the vehicles manufacturer (GVWR).***