

8052 JK REAR LOWER CONTROL ARMS

Version 4.0

GENERAL NOTES:

- These instructions are also available on our website. Check the website before you begin for any updated instructions and additional photos for your reference.
- The installation of these control arms will allow you to correctly align the rear axle after a suspension lift kit is installed.
- These control arms feature a double adjuster sleeve which allows you to adjust the length of the arm without removing the arm from the vehicle.
- 1. The control arms come assembled to the shortest length. Make any length adjustments by only turning the adjuster sleeve so there is equal thread on the flex joint and adjuster sleeve.
- 2. We recommend that you preset the length of the lower control arms. For 3-4.5" of lift, we recommend a length of 20.25" measured from the center to center of the bushings. This length works well when using the stock length upper control arms and for longer upper control arms when using a CV style rear drive line. If you need to point the pinion up to use a CV style rear driveline, try to only lengthen the upper arms and leave the lowers at 20.25".
- 3. Remove the existing lower control arms. If you are just replacing the lower control arms, they can be replaced one at a time with the vehicle sitting on level ground, without removing the tires & wheels or any other suspension part.
- 4. Install the new control arms with the bushing at the axle end and the forged flex joint at the frame end. Position the arm with the pinch bolt on the top of the control arm. Reuse the factory mounting bolts.
- 5. Tighten the factory control arm bolts to 125 ft-lbs. Once final length adjustments are made, tighten the pinch bolt to 80 ft-lbs. Put a wrench on the adjuster sleeve at this time and try to move the adjuster. Make sure pinch bolt has adequately clamped onto flex joint shank so that the adjuster is not movable. If movable, increase torque on pinch bolt but do not exceed 90 ft-lbs.
- 6. Installation Complete.



