

➤ Instructions









Thule OutRide
561



Roof-mounted bike carrier

CITY CRASH

Complies with ISO norm




i



Thule WingBar





Thule AeroBar



Thule SquareBar



Aluminium bars





Not ok Non-compatible bike fork drop outs.

Not ok Carbon Fiber/Carbon



ok

Not ok


1





2




i



Square bars



Aluminium bars





Thule WingBar/AeroBar
or other 20 mm T-track

➔ 3 - 6 ➔ 10


➔ 7 - 9 ➔ 10

3




* Only a few turns





4




5



6




7




*



Only a few turns










8





9




10




11




12




i A-C




A




B




C






Accessories



PLEASE NOTE: When the bicycle is not attached the clamping sleeve (Figure 10:4) can lose its clamping force. Therefore step 10 must always be carried out when the bicycle is attached.

Thule One-Key System



512  (x2)

544  (x4)

596  (x6)

588  (x8)

Thule Wheel On

593

