




Tool Box

Aluminum Crossover Box



Part No. 110511, 110601, 110631, 110632, 110701, 110702, 110721, 110722, 111701, 111702, 111721, 111722, 120601, 120631, 120632, 120701, 120702, 120721, 120722, 121701, 121721, 140601, 140701, 140721, 110703, 110723, 120633, 120703, 120723, 110603, 120602



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



30-60 min




Cutting Not Required



Drilling Required

Aluminium Crossover Box



PARTS INCLUDED



PARTS INCLUDED


| part | Description / Description / <i>Descripcion</i> | qty. |
|------------------------|---|------|
| A | Aluminum crossover toolbox | 1 |
| B | Key | 2 |
| C | Tray with dividers (included in certain models) | 1 |
| D | Rail pad | 2 |
| UWS - JBOLT KIT | | 1 |
| E | 3" j-hook | 2 |
| F | 1/4" washer | 2 |
| G | 1/4" nut | 2 |

TOOLS REQUIRED



| part | Description | qty. |
|------|---------------|------|
| A | Tape measure | 1 |
| B | Socket wrench | 1 |
| C | 1/2" socket | 1 |

1. Check for clearance with lid open.




Attach adhesive side of rail pad (D) to underside of toolbox ends.

Place box (A) with rail pads (D) on top of truck bed rails.

Use tape measure to ensure box is centered in the truck bed.


Open lid and locate box ensuring there is clearance between open lid top and back of cab.

2. ATTACH BOX TO THE TRUCK BED



Place “J-hook” (E) under lip of bed rail and insert threaded end up through slot.

Attach with washer (F) and nut (G) hand tighten, repeat on other side.



Only use one hole and J-hook assembly on each side.

Re-measure with tape measure to ensure box is centered and allows lid clearance when open.

Fully tighten with socket wrench.

3. STRIKER INFORMATION

Boxes come with an adjustable striker. If the striker should ever be accidentally knocked out of alignment, simply loosen, re-adjust and tighten.



Periodically lubricate strikers and locks to ensure optimum performance.

PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, please ensure that holes are not partially covered with any plastic grommet or rust? If it is, please remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Please ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Please refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.