



Tool Box Aluminum Chest Box




Part No. 150361, 150401, 150481, 150482, 150562, 150581,
150601, 150602, 151481, 151601, 152601, 152602



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.




READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



30-60 min



Cutting Not Required



Drilling Required

Aluminium Chest Box

PARTS INCLUDED



A




B

PARTS INCLUDED

part	Description	qty.
A	Aluminum chest toolbox	1
B	Key	2

TOOLS REQUIRED

A



B



C




D



part	Description	qty.
A	Drill	1
B	5/16" drill bit	1
C	Tape measure	1
D	Socket wrench	1


1.

BACK OF BOX



Drill two 5/16" holes in the back of the box (A) using the approximate locations shown here.

2. INSTALLATION / INSTALLATION / INSTALACIÓN



Place box (A) in the pick up truck bed pushed to the front of the truck bed and centered side to side.

Use holes in box as a guide to mark location for holes on truck bed wall.

Move box (A) out of the way to back of bed.


Drill 5/16" holes in both marked locations on the truck bed wall.

Place box (A) back in location and line up holes.

WARNING: Before drilling into your truck bed, check under your vehicle to ensure the drill location does not puncture, cut or obstruct any brake or fuel fluid lines, electrical wires, fuel tanks, etc. Mounting bolts should be installed from the underside to help prevent any damage underneath your vehicle.

3.

BACK OF BOX



Place hex bolt (D) with flat washer (F) through the drilled hole in box and bed wall.

Attach by placing a flat washer (F), nylon lock nut (E) on bolt in front of truck bed.


Repeat on other side.

Use a silicone type caulk to fill in any open areas around bolt.

Tighten all securely.

4.

BACK OF BOX



Boxes come with an adjustable striker. If the striker should ever be accidentally knocked out of alignment, simply loosen, re-adjust and tighten.

Periodically lubricate strikers and locks to ensure optimum performance.

PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, please ensure that holes are not partially covered with any plastic grommet or rust? If it is, please remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Please ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Please refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.