



5" Oval W2W Nerf Bar

Part No. A7026S/B



Fits: 2007 - Current


Toyota Tundra Double Cab 6.5' Standard Bed



Can Fit in Diesel Trucks



120-240 min



Cutting Not Required




Drilling Not Required



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.




READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.

PARTS LIST:


Qty	Part Description	Qty	Part Description
1	Driver Sidebar	2	10mm Plastic Retainers
1	Passenger Sidebar	2	10mm x 30mm Bolt Plates
1	Driver/Left Front Mounting Bracket	2	10mm x 27mm x 3mm Flat Spacer Washers
1	Passenger/Right Front Mounting Bracket	2	10mm Lock Washers
1	Driver/Left Middle Mounting Bracket	2	10mm x 30mm x 2.5mm Flat Washers
1	Passenger/Right Middle Mounting Bracket	2	10mm Hex Nuts
1	Driver/Left Rear Mounting Bracket	28	8-1.25mm x 30mm Hex Bolts
1	Passenger/Right Rear Mounting Bracket	28	8mm Lock Washers
1	Driver/Left Rear Support Bracket	28	8mm x 24mm OD x 2mm Flat Washers
1	Passenger/Right Rear Support Bracket		



IMPORTANT: There are four sets of threaded holes in the side panel. Starting from the front of the vehicle, use the first, second, and fourth set of holes.

INSTALLATION PROCEDURE

1. Starting on the driver side front of the vehicle, remove the existing (2) factory bolts, (or plastic plugs), on the side panel located by the front tire opening, **(Figure 1)**. Attach the front Mounting Bracket to the vehicle using the included (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, **(Figure 2)**. Do not tighten hardware at this time.



(Fig 1) Driver/Left Front Mounting Location Pictured






Fig 2


2. Locate the next mounting location along the side panel closest to the front Bracket and the very last location toward the back of the cab. Remove the factory bolts, (or plastic plugs), as described in **Step 1**. Select the correct driver side Center and Rear Brackets and bolt them to the body panel as described in **Step 1**, **(Figures 3 - 5)**. Do not tighten hardware at this time.





(Fig 3) Driver/Left Center Mounting Location Pictured




(Fig 4) Driver/Left Center Bracket Pictured



3. Move to the very end of the cab. Locate and remove the rubber plug in the side of the inner body panel, (Figure 6). Select (1) 10mm Bolt Plate and (1) Plastic Retainer, (Figure 7B). Insert the Bolt Plate into the hole and thread the Plastic Retainer down onto the Bolt Plate until it is tight against the body panel, (Figure 7A). **NOTE:** The Plastic Retainer is designed to prevent the Bolt Plate from falling into the body panel and to aid Support Bracket installation. Select (1) 10mm x 27mm Thick Flat Spacer Washer and slide it onto the threaded end of the Bolt Plate over the Retainer, (Figure 7A). Next, secure the driver side Rear Support Bracket to the Bolt Plate with (1) 10mm x 30mm x 2.5mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, (Figure 8). Snug but do not fully tighten hardware at this time.



10mm x 30mm x 2.5 STD Flat Washer
10mm Lock Washer
10mm Hex Nut



4. Carefully place the Driver/Left Sidebar onto the (4) Brackets. Align the threaded holes in the bottom of the Sidebar with the slots in the Mounting Brackets. Attach the Sidebar to the Mounting Brackets with the included (8) 8mm x 30mm Hex Bolts, (8) 8mm Lock Washers and (8) 8mm Flat Washers, (**Figures 2, 4 & 5**). Do not tighten hardware at this time.
5. Level and adjust the Sidebar properly and tighten all hardware.
6. Repeat **Steps 1 - 5** for passenger Sidebar installation.




PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "PR"
2	Driver / Left 'Rear' Bracket marked "DR"
3	Passenger / Right 'Center' Bracket marked "PC"
4	Driver / Left 'Center' Bracket marked "DC"
5	Passenger / Right 'Front' Bracket marked "PF"
6	Driver / Left 'Front' Bracket marked "DF"

Note:

- This guide is to identify the parts and not a reference for part count.
- For part count, refer Parts List.
- Product / Bracket image is representative and actual design may vary.



PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.