




5" Oval W2W Nerf Bar

Part No. A7062S/B




Fits: 2009 - Current Dodge Ram 1500 Crew Cab 8Ft Long Bed
 2010 - Current Dodge ram 2500/3500 Crew Cab 8Ft Long Bed



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.




READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



60-180 min




Cutting Not Required



Drilling Required

PARTS LIST:

Qty	Part Description	Qty	Part Description
1	Driver/Left Sidebar	5	12mm Lock Washers
1	Passenger/Right Sidebar	5	12mm Hex Nuts
1	Driver/Left Front Mounting Bracket	6	10-1.5mm x 35mm Hex Bolts
1	Driver/Left Front Support Bracket	4	10-1.5mm x 30mm Hex Bolts
2	Driver/Left Center/Rear Mounting Brackets	10	10mm x 27mm OD x 3mm Flat Washers
3	Passenger/Right Mounting Brackets	10	10mm Lock Washers
1	Driver/Left Rear Bed Mounting Bracket	7	8-1.25mm x 30mm Hex Bolts
1	Driver/Left Rear Double Nut Plate	16	8-1.25mm x 25mm Hex Bolts
1	Passenger/Right Rear Bed Mounting Bracket	24	8mm x 24mm x 2mm Flat Washers
1	Passenger/Right Rear Double Nut Plate	22	8mm Lock Washers
6	12mm Plastic Retainers	1	8mm Nylon Lock Nut
6	12mm x 35mm Bolt x 10mm Nut Plates	4	6mm x 22mm x 2mm Flat washer
5	12mm x 32mm OD x 3mm Flat Washers	2	6mm x 25mm Hex Bolt
		2	6mm Nylon Lock Nut



INSTALLATION PROCEDURE:

1. Starting at the driver side-front of the vehicle, remove the sealing tape covering the factory holes on the side of the inner panel, **(Figure 1)**.
2. Determine the correct procedure to attach the driver side front Bracket for your model/year:
Models without factory threaded inserts in body panel:

- a. Partially thread a 12mm Plastic Retainer onto the threaded end of a 12mm Bolt and Nut Plate, **(Figure 2)**. Insert the Bolt and Nut Plate into the oval hole and tighten the Plastic Retainer, **(Figure 3)**. **NOTE:** The Plastic Retainer is designed to keep the Bolt/Nut Plate from falling into the body panel and to aid Bracket installation.
- b. Select the driver side front Mounting Bracket, **(Figure 5)**. Rotate the 12mm Bolt and Nut plate until the threaded nut lines up with the hole in the Mounting Bracket and body, **(Figure 3)**. Attach the Bracket to the threaded Nut Plate with (1) 10mm x 35mm Hex Bolt, (1) 10mm Lock Washer and (1) 10mm Flat Washer, **(Figures 5 & 7)**. Do not fully tighten hardware at this time.

Models with factory threaded inserts:

- a. Attach the driver side Front Bracket to the threaded insert with (1) 8mm x 30mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, **(Figures 4, 5 & 7)**. Leave hardware loose.
3. Next, select the driver side front Support Bracket. Attach the Bracket to the back of the front Bracket with (1) 8mm x 30mm Hex Bolt, (2) 8mm Flat Washers and (1) 8mm Nylon Lock Nut, **(Figures 5 & 7)**. Rotate the Support Bracket to the back of the pinch weld. Line up the slot in the top of the Support Bracket with the (2) factory holes in the pinch weld. Attach the Bracket to the pinch weld with (2) 6mm Hex Bolts, (4) 6mm Flat Washers and (2) 6mm Nylon Lock Nuts, **(Figures 6 & 7)**. Do not fully tighten hardware at this time. **IMPORTANT:** 2009-10 models are not equipped with factory holes and will require drilling through the pinch weld to attach the Support Bracket. Do not drill through pinch weld at this time, **(see Step 9)**.
 4. Move along the side of the body panel to the center mounting location, **(Figure 8)**. Select (1) 12mm Bolt/Nut Plate. Repeat **Step 3** to install the Bolt/Nut Plate. Select the driver side center Bracket. Attach the Bracket to the Bolt/Nut Plate with (1) 12mm Flat Washer, (1) 12mm Lock Washer and (1) 12mm Hex Nut, **(Figure 9)**. Do not tighten hardware at this time. Line up the remaining hole in the Bracket with the hole in the inner body panel. Rotate the Bolt and Nut Plate until the threaded end (Nut) lines up with the hole in the Bracket. Secure with (1) 10mm x 35mm Hex Bolt, (1) 10mm Lock Washer and (1) 10mm Flat Washer, **(Figure 9)**
 - a. **IMPORTANT NOTE:** Models with threaded insert, attach the Bracket to the threaded insert with (1) 8mm x 30mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer. The 10mm hardware will not be required **(Step 5)**. Snug but do not tighten hardware.
 5. Move to the rear location, **(Figure 10)**. Repeat **Step 5** to install the rear Mounting Bracket, **(Figure 11)**. **NOTE:** Driver/left side center and rear cab mounting Brackets are identical. .
 6. Once the (3) driver side cab Brackets have been installed, move to the driver side rear bedside support bracket in front of the rear tire opening, **(Figure 12)**. Select the driver side Rear Bed Bracket and Double Nut Plate, **(Figure 14)**. Slide the Double Nut Plate into position on the back of the support bracket with the (2) welded hex nuts facing forward inside the factory support bracket, **(Figure 13)**. Hold the rear Bed Bracket up in place in front of the support bracket. Line up the (2) mounting holes and attach the Bracket to the Nut Plate with the included (2) 10mm x 30mm Hex Bolts, (2) 10mm Lock Washers and (2) 10mm Flat Washers, **(Figure 14 & 15)**. Do not tighten hardware at this time.
 7. Once all (4) of the driver side Brackets have been installed, with assistance, carefully position the driver Sidebar onto the Brackets. Attach the Sidebar to the Brackets with the included (8) 8mm x 25mm Hex Bolts, (8) 8mm Lock Washers and (8) 8mm Flat Washers, **(Figure 16)**. Do not tighten hardware.
 8. Properly level and adjust the Sidebar and fully tighten all hardware.
2009-10 models requiring drilling for driver side front Support Bracket:
 - a. Make sure the Sidebar is level to the vehicle. Line up the slot on the Support Bracket with the back of the pinch weld. Mark the location of the slot onto the pinch weld.
 - b. Drill (2) 1/4" holes through the pinch weld. **IMPORTANT:** Do not drill too close to the bottom edge of the pinch weld. Drill the holes toward the outside of the marked slot.


IMPORTANT! Any cutting or drilling tool may break or shatter. Government regulations require safety glasses & equipment at all times when cutting or drilling.

 - c. Attach the Support Bracket to the pinch weld with (2) 6mm Hex Bolts, (4) 6mm Flat Washers and (2) 6mm Nylon Lock Nuts, **(Figures 6 & 7)**. Check for level then fully tighten all hardware.
 9. Repeat **Steps 5—9** to install the passenger/right side Brackets. **NOTE:** Passenger side front, center and rear Brackets are identical and no front Support Bracket is required, **(Figure 17)**.
 10. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Driver Side Installation Pictured




(Fig 1) Driver/Left front mounting location




(Fig 2) 12mm x 35mm Bolt/10mm Nut Plate with 12mm Plastic Retainer

Rotate Bolt/Nut Plate to line up threaded hole with body panel and hole in Mounting Bracket (see arrow)


12mm x 35mm Bolt/10mm Nut Plate
12mm Plastic Retainer



(Fig 3) Driver side front 2011 to mid 2015. NOTE no threaded insert in body panel



(Fig 4) Driver side front mid 2015-on. Example of all models with factory installed threaded inserts



(Fig 5) Driver/Left front Mounting Bracket assembly


Models without threaded insert using Bolt/Nut Plate, use:
10mm x 35mm Hex Bolt
10mm Lock Washer
10mm Flat Washer

Models with threaded insert use:
8mm x 30mm Hex Bolt
8mm Lock Washer
8mm Flat Washer

8mm x 30mm Hex Bolt
(2) 8mm Flat Washers
8mm Nylon Lock Nut

Driver Side Installation Pictured


- (2) 6mm Hex Bolt
- (4) 6mm Flat Washers
- (2) 6mm Nylon Lock Nut



(Fig 6) Attach Support Bracket to back of pinch weld


Models without threaded insert using Bolt/Nut Plate, use:
 10mm x 35mm Hex Bolt
 10mm Lock Washer
 10mm Flat Washer

Models with threaded insert use:
 8mm x 30mm Hex Bolt
 8mm Lock Washer
 8mm Flat Washer



(Fig 7) Driver side 2011-on model with factory holes in pinch weld pictured.

IMPORTANT: 2009-2010 models without holes in pinch weld will require drilling 1/4" holes through pinch weld to attach driver side front support bracket. Do complete installation of sidebars first, level sidebar before drilling holes for support bracket.




(Fig 8) Driver/Left center mounting location

- 12mm Flat Washer
- 12mm Lock Washer
- 12mm Hex Nut


Models without threaded insert using Bolt/Nut Plate, use:
 10mm x 35mm Hex Bolt
 10mm Lock Washer
 10mm Flat Washer

Models with threaded insert use:
 8mm x 30mm Hex Bolt
 8mm Lock Washer
 8mm Flat Washer



(Fig 9) Driver/Left center Bracket

Driver Side Installation Pictured




(Fig 10) Driver/Left rear location


Models without threaded insert using Bolt/Nut Plate, use:
 10mm x 35mm Hex Bolt
 10mm Lock Washer
 10mm Flat Washer

Models with threaded insert use:
 8mm x 30mm Hex Bolt
 8mm Lock Washer
 8mm Flat Washer

12mm Flat Washer
 12mm Lock Washer
 12mm Hex Nut




(Fig 11) Driver/Left rear cab Mounting Bracket




(Fig 12) Driver/left rear bed mounting location

(2) 10mm x 30mm Hex Bolts
 (2) 10mm Lock Washers
 (2) 10mm Flat Washers




(Fig 14) Driver/left Bed Mounting Bracket

Driver/left 10mm
 Double Nut Plate



(Fig 13) Driver/left Double Nut Plate



- (2) 10mm x 30mm Hex Bolts
- (2) 10mm Lock Washers
- (2) 10mm Flat Washers

Fig 15


Models without threaded insert using Bolt/Nut Plate, use:
 10mm x 35mm Hex Bolt
 10mm Lock Washer
 10mm Flat Washer

Models with threaded insert use:
 8mm x 30mm Hex Bolt
 8mm Lock Washer
 8mm Flat Washer



- 8mm x 25mm Hex Bolts
- 8mm Flat Washers
- 8mm Lock Washers

(Fig 16) Driver/Left rear Mounting Bracket



- 8mm x 25mm Hex Bolts
- 8mm Flat Washers
- 8mm Lock Washers

(Fig 17) Passenger/right front Mounting Bracket



Complete Installation


PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "PR"
2	Driver / Left 'Rear' Bracket marked "DR"
3	Passenger / Right 'Center' Bracket marked "PC"
4	Driver / Left 'Center' Bracket marked "DC"
5	Passenger / Right 'Front' Bracket marked "PF"
6	Driver / Left 'Front' Bracket marked "DF"

Note:

- This guide is to identify the parts and not a reference for part count.
- For part count, refer Parts List.
- Product / Bracket image is representative and actual design may vary.



PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.