




INSTALLATION INSTRUCTIONS

5" OVAL WHEEL TO [WHEEL SIDEBARS](#)

10-15 DODGE RAM 25-3500 MEGA CAB 6-1/2FT BED EXCLUDES
MODELS WITH DUAL REAR WHEELS
PART NUMBER# 1-07536 1-57536

PARTS LIST:

Qty	Description	Qty	Description
1	Driver/Left Sidebar	8	12mm Lock Washers
1	Passenger/Right Sidebar	8	12mm Hex Nuts
3	Driver/Left 1 st , 2 nd & 3rd Mounting Brackets	8	10-1.5mm x 35mm Hex Bolts
3	Passenger/Right 1 st , 2 nd & 3rd Mounting Brackets	8	10mm x 27mm OD x 3mm Flat Washers
1	Driver/Left Rear Fourth Bracket	8	10mm Lock Washers
1	Passenger/Right Rear Fourth Bracket	16	8-1.25 x 25mm Hex Bolts
8	12mm Plastic Retainers	16	8mm x 24mm x 2mm Flat Washers
8	12mm x 35mm Bolt x 10mm Nut Plates	16	8mm Lock Washers
8	12mm x 32mm OD x 3mm Flat Washers		



PROCEDURE:

- REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. DRILLING IS OPTIONAL.**
- Starting at the driver side-front of the vehicle, remove the sealing tape covering the factory holes on the side of the inner panel, **(Figure 1)**. Partially thread (1) 12mm Plastic Retainer onto the threaded end of (1) 12mm Bolt and Nut Plate, **(Figure 2)**. Insert the Bolt and Nut Plate into the factory oval hole. Continue to thread the Plastic Retainer down the Bolt and Nut Plate until it is flush against the sheet metal, **(Figure 3)**. **NOTE:** When properly installed, the Plastic Retainer will prevent the Bolt and Nut Plate from falling into the body cavity during installation.
- Select the driver side front Mounting Bracket and hang it from the Bolt and Nut Plate with (1) 12mm Flat Washer, (1) 12mm Lock Washer and (1) 12mm Hex Nut, **(Figure 4)**. Do not tighten hardware at this time. Line up the remaining hole in the Mounting Bracket with the hole in the body panel. Rotate the Bolt and Nut Plate until the threaded end, (Nut), lines up with the hole in the Mounting Bracket. Secure the Bracket with (1) 10mm x 35mm Hex Bolt, (1) 10mm Lock Washer and (1) 10mm Flat Washer, **(Figure 5)**. Snug but do not tighten hardware at this time.
- Repeat **Steps 2 - 3** for the center-front and center-rear Mounting Bracket installation.
- Once the (3) driver side Brackets have been installed, carefully position the driver Sidebar onto the Mounting Brackets. Attach the Sidebar to the cradles on the Mounting Brackets with the included (6) 8mm x 25mm Hex Bolts, (6) 8mm Lock Washers, and (6) 8mm Flat Washers, **(Figure 6)**. Do not tighten hardware at this time. **IMPORTANT:** If you are having any difficulty with installation, check Mounting Bracket location first. Use the illustration on **Page 1** to identify the Mounting Brackets.
- Insert (1) 12mm Bolt and Nut Plate with Plastic Retainer into the hole in the rear corner of the cab as described in Step 2, **(Figures 7 & 8)**. Select the driver side Rear Mounting Bracket, **(Figure 9)**. **NOTE:**

The rear Bracket looks similar to the other Brackets but they are unique and only designed to fit the rear mounting location. Hang the Rear Bracket from the Bolt Plate with (1) 12mm Flat Washer, (1) 12mm Lock Washer and (1) 12mm Hex Nut, (**Figure 10**). Leave hardware loose. Attach the Bracket to the Sidebar with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, (**Figure 6**). Properly level and adjust the Sidebar and tighten all hardware at this time.

- 7. Optional Rear Bracket Installation**-requires drilling-highly recommended for heavy duty use:
- Once **Step 6** has been completed, loosen the Hex Nut on the Bolt Plate and center the threaded end in the slot in the Bracket and the vehicle, (**Figures 8 & 10**). Trace the open, unused slot in the bracket mounting plate onto the body panel, (**Figure 10**). Remove the Rear Bracket and Bolt Plate, (**Figure 11**). Mark the center of the slot. Carefully drill the location with a 7/16" drill bit, (**Figure 12**). Reinstall the Bolt Plate and Bracket as previously described in **Steps 2 - 3 & 6**, (**Figure 13**). Tighten all hardware.

IMPORTANT! Any cutting or drilling tool may break or shatter. Government regulations require safety glasses & equipment at all times when cutting or drilling.


- Repeat **Steps 2 – 6 (or 7)** for passenger Sidebar installation.
- Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.


For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

For gloss black finishes: Mild soap may be used to clean the Sidebar.


Driver Side Installation Pictured



(Fig 1) Driver/Left front mounting location pictured




12mm x 35mm Bolt x
10mm Nut Plate
12mm Plastic Retainer



12mm x 35mm Bolt x 10mm Nut
Plate w/ 12mm Plastic Retainer

Driver Side Installation Pictured



12mm Flat Washer
 12mm Lock Washer
 12mm Hex Nut

Front →

(Fig 4) Driver/Left front Mounting Bracket

10mm x 30mm Hex Bolt
 10mm Flat Washer
 10mm Lock Washer





Fig 5


Front →



Front →

Fig 6

8mm x 25mm Hex Bolts
 8mm Flat Washers
 8mm Lock Washers



(Fig 7) Driver side rear mounting location at end of cab

Rear →

12mm x 40mm Bolt x 10mm Nut
 Plate w/ 12mm Plastic Retainer





Fig 8

IMPORTANT: The rear Mounting Brackets look similar to the front and center brackets but they are unique. Note the reversed mounting plate and rear facing cradle for the Sidebar.

Try to keep the Bolt Plate in the center of the slot when installing the rear Bracket only




(Fig 9) Driver /Left Rear Bracket Pictured

Rear →

Driver Side Installation Pictured

12mm Flat Washer
12mm Lock Washer
12mm Hex Nut



(Fig 10) Driver/Left rear Mounting Bracket

Trace the slot with a marker.
Locate approximate center
of slot and mark to drill




Fig 11

Use a 7/16" drill bit to drill hole
in center of slot as marked




Fig 12

12mm Flat Washer
12mm Lock Washer
12mm Hex Nut




Fig 13

10mm x 30mm Hex Bolt
10mm Flat Washer
10mm Lock Washer



Complete Installation