



Part # 16962
1999 - 2003 Chevy or GMC 1500
Suburban or Tahoe w/ 5 link rear end
Strong 6" suspension system

Parts contained in Box 1 of 3

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
16955-16	Front cross member	1
16955-17	Rear cross member	1
16955-18	6" integrating skid plate	1
16955-10	Front lateral compression arms	2
16965NB	Hardware bag	1

Parts contained in Box 2 of 3

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
DSDIFF-01	DS differential relocation bracket	1
16955-06	PS differential relocation bracket	1
16955-11	Rear lateral compression arm mounts	2
16965-05	DS front shock relocation bracket	1
16965-06	PS front shock relocation bracket	1
16965-12	Rear coil spring spacers	2
16965-13	DS/PS rear shock relocation bracket	2
14965-27	DS/PS torsion bar shims	4
16965-11	Rear track bar relocation bracket	1
SB-03	Rear sway bar end links	2
16965PL	Hardware bag	1
16965SL	Hardware bag	1
14959NB1	Hardware bag	1
9804	1" axle spacers	2
S10120	DS differential sleeve	1
16962INST	Instruction manual (customer copy)	1
16962INST	Instruction manual (Installer copy)	1
MIRRORHANGER	Rear view mirror hanger	1
WARNINGDECAL	Warning decal	1
DECAL	Window sticker	1

Parts contained in Box 3 of 3

<u>Part #</u>	<u>Description</u>	<u>Qty.</u>
16955-01M	Driver side knuckle	1
16955-02M	Passenger side knuckle	1

Congratulations on your selection to purchase a Tuff Country EZ-Ride Suspension System. We at Tuff Country are proud to offer a high quality product at the industries most competitive pricing. Thank you for your confidence in us, and our product.

Before installation begins, it is the customers/installers responsibility to make sure that all parts are on hand. If any parts are missing, please feel free to call one of our customer service representatives @ (801) 280-2777.

Installation manual
Strong 6" suspension system
1999 - 2003 Chevy or GMC 1500
Suburban or Tahoe w/ 5 link rear end

Part # 16962

sj0202707rev.01

Important customer information:

Tuff Country EZ-Ride Suspension highly recommends that a qualified and/or certified mechanic performs this installation.

If you desire to return your vehicle to stock, it is the customers responsibility to save all stock hardware.

This vehicles reaction and handling characteristics may differ from standard cars and/or trucks. Modifications to improve and/or enhance off road performance may raise the intended center of gravity. Extreme caution must be utilized when encountering driving conditions which may cause vehicle imbalance or loss of control. DRIVE SAFELY! Avoid abrupt maneuvers, such as sudden sharp turns which could cause a roll over, resulting in serious injury or death.

It is the customers responsibility to make sure that a re-torque is performed on all hardware associated with this suspension system after the first 100 miles of installation. It is also the customers responsibility to do a complete re-torque after every 3000 miles or after every off road use.

After the original installation, Tuff Country EZ-Ride Suspension also recommends having the alignment checked every 6 months to ensure proper tracking, proper wear on tires and front end components. Tuff Country EZ-Ride Suspension takes no responsibility for abuse, improper installation or improper suspension maintenance.

It is the responsibility of the customer or the mechanic to wear safety glasses at all times when performing this installation.

It is the customers/installers responsibility to read and understand all steps before installation begins. OEM manual should be used as a reference guide.

Make sure to use lock tite on all new and stock hardware associated with this installation.

The Tuff Country EZ-Ride Suspension product safety label that is included in your kit box must be installed inside the cab in plain view of all occupants.

Limited lifetime warranty

Notice to all Tuff Country EZ-Ride Suspension customers: It is your responsibility to keep your original sales receipt! If failure should occur on any Tuff Country EZ-Ride Suspension component, your original sales receipt must accompany the warranted unit to receive warranty. Warranty will be void if the customer can not provide the original sales receipt. Do not install a body lift in conjunction with a suspension system. If a body lift is used in conjunction with any Tuff Country EZ-Ride Suspension product, your Tuff Country EZ-Ride Suspension WARRANTY WILL BE VOID. Tuff Country Inc. ("Tuff Country") suspension products are warranted to be free from defects in material and workmanship for life if purchased, installed and maintained on a non-commercial vehicle; otherwise, for a period of twelve (12) months, from the date of purchase and installation on a commercial vehicle, or twelve thousand (12,000) miles (which ever occurs first). Tuff Country does not warrant or make any representations concerning Tuff Country Products when not installed and used strictly in accordance with the manufacturer's instructions for such installation and operation and accordance with good installation and maintenance practices of the automotive industry. This warranty does not apply to the cosmetic finish of Tuff Country products nor to Tuff Country products which have been altered, improperly installed, maintained, used or repaired, or damaged by accident, negligence, misuse or racing. ("Racing is used in its broadest sense, and, for example, without regards to formalities in relation to prizes, competition, etc.) This warranty is void if the product is removed from the original vehicle and re-installed on that or any other vehicle. This warranty is exclusive and is in lieu of any implied warranty of merchantability, fitness for a particular purpose or other warranty of quality, whether express or implied, except the warranty of title. All implied warranties are limited to the duration of this warranty. The remedies set forth in this warranty are exclusive. This warranty excludes all labor charges or other incidental of consequential damages. Any part or product returned for warranty claim must be returned through the dealer of the distributor from whom it was purchased. Tuff Country reserves the right to examine all parts returned to it for warranty claim to determine whether or not any such part has failed because of defect in material or workmanship. The obligation of Tuff Country under this warranty shall be limited to repairing, replacing or crediting, at its option, any part or product found to be so defective. Regardless of whether any part is repaired, replaced or credited under this warranty, shipping and/or transportation charges on the return of such product must be prepaid by the customer under this warranty.

Important information that needs to be read before installation begins:

The stock wheels will not work in conjunction with this suspension system. New wheels with a 4.5" back spacing is required. Tuff Country recommends a 35x12.50 tire package. If larger than a 35x12.50 tire is installed on your vehicle in conjunction with part # 16962; Tuff Country assumes no liability and the warranty will be VOID.

Before installation begins, Tuff Country EZ-Ride Suspension highly recommends that the installer performs a test drive on the vehicle. During the test drive, check to see if there are any uncommon sounds or vibrations. If uncommon sounds or vibrations occur on the test drive, uncommon sounds or vibrations will be enhanced once the suspension system has been installed. Tuff Country EZ-Ride Suspension highly recommends notifying the customer prior to installation to inform the customer of these issues if they exist.

After installation, some vehicle may encounter a front drive line vibration. If this is the case on the vehicle that you are working on, the stock front drive line may need to be rebalanced. If the stock front drive line is rebalanced and the vibration still occurs, a new front drive line may be needed.

Tuff Country EZ-Ride Suspension packages (2) sets of instruction sheets with this box kit. (1) is for the installer and (1) is for the customer. The (1) for the customer has some post installation procedure literature and it is the installers responsibility to make sure that the customer receives a copy of the installation manual along with the literature.

Torque settings:

5/16"	15—18 ft lbs.
3/8"	28—32 ft lbs.
7/16"	30—35 ft lbs.
1/2"	65—85 ft lbs.
9/16"	85—120 ft lbs.
5/8"	95—130 ft lbs.
3/4"	100—140 ft lbs.

Hardware bag 16965SL includes:

<u>Description</u>	<u>Quantity</u>
S10019 (.750" x .563" x 1.190")	2
S10020 (.750" x .563" x 1.750")	2
S10026 (.680" x .500" x 1.500")	4
S10058 (.875" x .500" x 2.080")	4
S10074 (.700" x .563" x 1.500")	2
S10082 (.875" x .563" x 2.080")	1
S10110 (.750" x .563" x 9.500")	2

Hardware bag 16965PL includes:

<u>Description</u>	<u>Quantity</u>
PB6199 (bump stop)	2
PB2408 (poly bushing)	10
MO2220 (poly bushing)	12
PB10630018 (Sway bar bushing)	8
S10113 (Sway bar end link washer)	8
SUW-916 (9/16" u-bolt washer)	2
BLR01 (brake line relocation bracket)	2
5161B (5/16" x 1" bolt)	1
14WA (1/4" USS flat washer)	2
516UN (5/16" unitorque nuts)	1
LUBE (poly lube pack)	2

Hardware bag 14959NB1 includes:

<u>Description</u>	<u>Quantity</u>
1/2" x 1 1/2" bolts	6
7/16" USS flat washers	12
1/2" unitorque nuts	6

Hardware bag 16965NB includes:

Bag # 1

<u>Description</u>	<u>Quantity</u>
5/16" USS flat washers	2
3/8" unitorque nuts	2
3/8" x 3/4" self threading bolts	10
5/16" x 1" bolt	1
10 mm x 55 mm bolts	12
10 mm lock washers	16
10 mm x 60 mm bolts	4
1/4" USS flat washers	2
5/16" unitorque nuts	1
All thread rod	2

Bag # 2

<u>Description</u>	<u>Quantity</u>
7/16" x 1 1/4" bolts	2
7/16" x 1 1/2" bolts	2
7/16" x 3" bolts	1
7/16" unitorque nuts	5
3/8" USS flat washers	10

Bag # 3

<u>Description</u>	<u>Quantity</u>
1/2" x 1 1/2" bolts	1
1/2" x 2 1/2" bolts	4
1/2" x 3 1/2" bolts	4
1/2" unitorque nuts	11
7/16" USS flat washers	18
1/2" x 15" bolts	2

Bag # 4

<u>Description</u>	<u>Quantity</u>
9/16" x 1 3/4" bolts	2
9/16" x 3" bolts	4
9/16" x 3 1/2" bolts	5
9/16" unitorque nuts	11
1/2" USS flat washers	26

Bag # 5

<u>Description</u>	<u>Quantity</u>
5/8" x 4 1/2" bolts	2
5/8" x 5 1/2" bolts	2
5/8" unitorque nuts	4
9/16" USS flat washers	8

Special note: Before installation begins, it is the customers/installers responsibility to make sure that all parts are on hand. If any parts are missing, please feel free to call one of our customer service representatives @ (801) 280-2777.

Special post installation procedure: Tuff Country EZ-Ride Suspension highly recommends adding a minimum of 1 pint, but no more that 1 1/2 pints, of proper front differential fluid into the front differential. To achieve this, you may have to fill the differential with it on its side or you may have to insert the fluid through the vent tube opening. On occasion, the customer may find burping of fluid coming out of the front vent tube.

Recommended tools selection:

- Torsion bar puller
(Part # 7822A / LSP code: 769 006 21)
- Cut off wheel
- Sawzall
- Torque wrench
- Standard socket set
- Standard wrench set
- Metric socket set
- Metric wrench set
- Tape measure
- Hydraulic floor jacks

Please follow instructions carefully:

Before installation begins, measure from the center of the hub, to the bottom of the fender well, and record measurements below.

Pre-installation measurements:

Driver side front: _____

Passenger side front: _____

Driver side rear: _____

Passenger side rear: _____

At the end of the installation take the same measurements and compare to the pre-installation measurements.

Post installation measurements:

Driver side front: _____

Passenger side front: _____

Driver side rear: _____

Passenger side rear: _____

Front end installation:

1. To begin installation, block the rear tires of the vehicle so that the vehicle is stable and can't roll backwards. Safely lift the front of the vehicle and support the frame with a pair of jack stands. Place a jack stand on both the driver and the passenger side. Next, remove the front wheels and tires from both sides.

2. Working on the driver side, attach the torsion bar removing tool to the stock torsion bar cross member, making sure that the unloading bolt in the center of the torsion bar removing tool is in the small divot of the stock torsion bar key. Adjust the torsion bar key up high enough so that the stock small metal adjusting block and bolt can be removed. Set the stock torsion bar block and hardware aside for later re-installation. Repeat procedure on passenger side.

Photo # 1 / Photo # 2

3. Mark both torsion bars before removal so that they can be re-installed back into the same location. **Example: Driver vs. Passenger and front vs. rear.** Tap the stock torsion bars forward until the stock torsion bar cross member can be removed. Once you tap the stock torsion bar out of the stock torsion bar cross member, the stock torsion bar key will fall out. Set the stock torsion bar key aside for later re-installation. Repeat procedure on the passenger side.

Photo # 3 / Photo # 4

4. Working on the driver side, remove the stock hardware that connects the stock torsion bar cross member to the stock mounting point. Set the stock hardware aside for later re-installation. **Special note: The stock mounting point is on the inside of the stock frame rail.** Repeat

procedure on the passenger side. Remove the stock torsion bar cross member from the stock location and set aside for later re-installation.

Photo # 5

5. Working on the driver side, slide the stock torsion bar out of the stock rear lower control arm and set aside for later re-installation. Repeat procedure on passenger side.

6. Remove the stock lower skid plate and discard the stock lower skid plate. Save the (2) stock mounting bolts for later re-installation. The rear mounting hardware may be discarded.

Photo # 6

7. Remove the stock upper skid plate from the stock location. Save the stock upper skid plate and stock hardware for later re-installation.

Photo # 7

8. Working on the driver side, carefully remove the load sensor valve from the stock shock and let hang. Remove the stock hardware attaching the stock shock to the stock upper location. Save the stock hardware for later re-installation. Next, remove the stock shock from the stock lower mounting location. Save the stock lower shock hardware for later re-installation. Remove the stock shock from the stock location and set aside for later re-installation. **Special note: When removing the stock shock from the stock location take special care not to damage the load sensor valve at the top of the stock shock.** Repeat procedure on passenger side.

Photo # 8

9. Working on the driver side, carefully remove the stock actuator rod from the stock location and set aside for later re-installation. Repeat procedure on the passenger side.

10. Working on the driver side, remove the stock sway bar end link from the stock location and discard the stock end link and stock hardware. Repeat procedure on the passenger side.

Photo # 9

11. Working on the driver side, remove the stock nut that connects the stock outer tie rod ball joint to the stock steering knuckle. Set the stock nut aside for later re-installation. Carefully break the stock taper on the stock outer tie rod ball joint and remove the stock outer tie rod from the stock knuckle. **Special note: Hitting the stock knuckle with a hammer will make removal of the stock outer tie rod easier. Take special care not to rip or tear the stock outer tie rod ball joint dust boot.** Repeat procedure on the passenger side.

Photo # 10 / Photo # 11

12. Working on the driver side, remove the stock brake line bracket that connects to the top of the stock steering knuckle and save the stock hardware. Next, remove the stock bolt that connects the stock brake line bracket to the

stock upper control arm, and save hardware for later re-installation. Repeat procedure on the passenger side.

Photo # 12 / Photo # 13

13. Working on the driver side, locate the ABS line quick disconnect located above the stock upper control arm. Disconnect the ABS lines from each other. Also, disconnect the ABS line from any other mounting points on the stock frame rail, stock upper control arm and the stock brake line bracket that was removed from the stock knuckle in step #

12. Repeat procedure on the passenger side.

Photo # 14 / Photo # 15

Photo # 16 / Photo # 17

14. Working on the driver side, remove the (2) stock bolts that connect the stock brake caliper to the stock knuckle. Save the stock hardware for later re-installation. Using a bungee cord, carefully tie the stock brake caliper up and out of the way in the fender well. **Special note: Take special care not to kink or over extend the stock brake line.** Repeat procedure on the passenger side.

Photo # 18 / Photo # 19

15. Working on the driver side, remove the stock rotor and set aside for later re-installation. Repeat procedure on the passenger side.

Photo # 20

16. Working on the driver side, remove the stock cap right in the middle of the stock hub assembly. Set the stock cap aside for later re-installation. Repeat procedure on the passenger side.

Photo # 21

17. Working on the driver side, remove the stock hardware that connects the stock axle to the stock hub assembly. Save the stock hardware for later re-installation. Repeat procedure on the passenger side.

Photo # 22

18. Working on the driver side, scribe a mark on the CV plate and another directly across to the stock differential. This will allow you to re-install the stock CV back into the stock location at a later step. Repeat procedure on the passenger side.

Photo # 23

19. Working on the driver side, remove the (6) stock bolts holding the inner CV axle to the stock front differential. Discard the stock hardware. Carefully remove the stock CV axle from the stock location and set the stock CV axle aside for later re-installation. **Special note: During the removal of the stock CV axle, take special care not to damage the threads of the CV axle or the CV axle dust boot.** Repeat procedure on the passenger side.

Photo # 24

20. Working on the driver side, loosen but do not remove the stock nut that connects the stock upper control arm ball

joint to the stock steering knuckle. Carefully break the stock taper by striking the stock knuckle with a hammer. **Special note: Take special care not to damage the stock upper control arm ball joint or rip the stock upper control arm ball joint dust boot. For now, leave the stock upper control arm attached to the stock knuckle. We want to just break the stock taper for now.** Repeat procedure on the passenger side.

Photo # 25 / Photo # 26

21. Working on the driver side, loosen but do not remove the stock nut that connects the stock lower control arm ball joint to the stock steering knuckle. Carefully break the stock taper by striking the stock knuckle with a hammer. **Special note: Take special care not to damage the stock lower control arm ball joint or rip the stock lower control arm ball joint dust boot. For now, leave the stock lower control arm attached to the stock knuckle. We want to just break the stock taper for now.** Repeat procedure on the passenger side.

Photo # 27 / Photo # 28

22. Working on the driver side, move back to the stock nuts holding the stock upper control arm ball joint and the stock lower control arm ball joint to the stock steering knuckle and remove completely. Save the stock hardware for later re-installation. Carefully remove the stock hub assembly and the stock steering knuckle from the stock location and set aside for later re-installation. Repeat procedure on the passenger side.

23. Working on the driver side stock hub assembly, remove the (3) stock bolts that connect the stock hub assembly to the stock steering knuckle. Save the stock hardware for later re-installation. Carefully remove the stock knuckle from the stock hub assembly. **Special note: Striking the stock hub assembly with a hammer will make removal easier. Also, take special care not to damage the stock hub assembly during removal.** Set the stock hub assembly aside for further instructions. A new steering knuckle is used, the stock steering knuckle can be discarded. Repeat procedure on the passenger side knuckle.

Photo # 29 / Photo # 30

24. Locate the new driver side steering knuckle. Using the stock hardware that was removed from step # 23, secure the new driver side steering knuckle to the stock hub assembly. Torque to **133 ft lbs.** **Special note: make sure to use thread locker or lock tite.** Set the new driver side steering knuckle and hub assembly aside for further instructions. Repeat procedure on the passenger side.

Photo # 31

25. Working on the driver side, remove the stock front and rear hardware that connects the stock lower control arm to the stock location. Set the stock hardware and the stock lower control arm aside for later re-installation. Repeat procedure on the passenger side.

Photo # 32 / Photo # 33

26. Working on the driver side, remove the stock bolt that connects the lower rear portion of the stock front differential to the stock rear cross member. Save the stock hardware for later re-installation.

Photo # 34

27. Working on the passenger side, remove the (2) stock bolts that connect the stock rear cross member to the stock passenger side rear lower control arm mounting point. The (2) stock bolts may be discarded. Working on the driver side, remove the (2) stock bolts holding the stock rear cross member to the stock bracket that is welded to the stock rear lower control arm pocket. The (2) stock bolts and the stock rear cross member may be discarded.

Photo # 35 / Photo # 36

28. Working on the driver side, measure 2 1/8" towards the inside of the vehicle from the stock rear lower control arm mounting point, scribe a mark on the stock rear cross member. Using a hacksaw or suitable cutting tool, carefully cut off the stock rear cross member along the line that was scribed earlier in this step. The stock rear cross member may be discarded. **Special note: When making this cut, make sure that you cut all the way through the stock rear lower control arm mounting point. If this cut is not performed properly, the stock front differential will not seat properly when the front differential is lowered into the new rear cross member.** Also, at this time, cut the rest of the stock bracket off the stock rear lower control arm pocket. Take special care not to cut into the stock rear lower control arm pocket. **Special note: Tuff Country EZ-Ride highly recommends not using a cutting torch when performing step. Clean and dress up any exposed metal.**

Photo # 37 / Photo # 38

Photo # 39

29. Remove the stock front drive line from the stock front differential. Carefully tie the stock front drive line up and out of the way. Save the stock hardware for later re-installation.

Photo # 40 / Photo # 41

30. Working on the passenger side of the stock front differential, locate the wiring harness that connects the 4WD control panel to the front differential. Disconnect the 4WD wiring harness from the front differential. Tie the 4WD wiring harness up and out of the way. **Special Note: Take special care not to kink wiring. Also, disconnect the 4WD wire harness from any other attaching points of the front differential.**

Photo # 42

31. Working on the driver side of the stock front differential, locate and pull the vent tube off of the differential.

Photo # 43

32. Place a pair of hydraulic floor jacks under the front

differential, and carefully raise up on both hydraulic floor jacks at the same time, until they come into contact with the front differential.

33. Working on the driver side, remove the stock hardware that connects the upper driver side tab of the stock front differential to the stock location. Save the stock hardware for later re-installation.

Photo # 44

34. Working on the passenger side, remove the (2) stock nuts that connect the passenger side of the stock front differential to the stock location and save the stock hardware for later re-installation.

Photo # 45

35. Carefully lower down on both hydraulic floor jacks at the same allowing enough room to remove the front differential completely from the vehicle. With the help from a buddy, carefully remove the front differential completely from underneath the vehicle and set the stock front differential on the ground or on a work bench.

36. Working on the driver side of the stock front differential upper tab, measure 2" from the stock mounting point and scribe a mark on the stock front differential. Using a sawzall, carefully cut the upper tab off of the stock front differential and discard.

Photo # 46 / side view

Photo # 47 / pre cut view

Photo # 48 / nose cut off of the front differential

37. Locate the new driver side differential relocation bracket. Locate (2) PB2408 poly bushings from hardware bag 16965PL and (1) S10082 crush sleeve from hardware bag 16965SL. Install the new poly bushings and crush sleeve into the new driver side differential relocation bracket. **Special note: Make sure to use a lithium or moly base grease prior to inserting the new bushings into the new driver side differential relocation bracket. This will increase the life of the bushing as well as prevent squeaking.**

38. Locate (1) 7/16" X 3" bolt, (1) 7/16" unitorque nut and (2) 3/8" USS flat washers from hardware bag 16965NB2. Locate (4) 10 mm x 60 mm bolts and (4) 10 mm lock washers from hardware bag 16965NB1. Also, locate (1) S10120 sleeve that was packaged with the installer copy of the instruction manual. Working on the front differential, remove the (4) stock differential mounting bolts that connect to two halves of the front differential together. The stock hardware may be discarded. Secure the new driver side differential relocation bracket to the stock front differential using the new 10 mm x 60 mm bolts and hardware. **Special note: Get all (4) new 10 mm x 60 mm bolts started but do not tighten at this point.** Secure the lower portion of the new driver side differential relocation bracket to the stock front differential using the new 7/16" x 3" bolt and hardware and new spacer sleeve. Add some

thread locker or lock tite and torque to **34 ft. lbs.** Move back to the (4) new 10 mm x 60 mm bolts that hold the new driver side differential relocation bracket to the stock front differential and add some thread locker or lock tite and torque to **34 ft lbs.** **Special note: Make sure not to over tighten the stock and new hardware associated with the front differential. If bolts are over tightened, the stock front differential could crack. Also, Tuff Country EZ-Ride Suspension highly recommends adding a minimum of 1 pint, but no more that 1 1/2 pints, of proper front differential fluid into the front differential. To achieve this, you may have to fill the differential with it on its side or you may have to insert the fluid through the vent tube opening. On occasion, the customer may find burping of fluid coming out of the front vent tube.**

Photo # 49

39. Working on the passenger side stock mounting location on the stock front differential, carefully cut off the passenger side rear corner of the stock mounting surface.

Photo # 50 / Photo # 51

40. Locate the new passenger side differential relocation bracket and the stock hardware that was removed from step # 34. Working on the passenger side, install the new passenger side differential relocation bracket into the stock upper location and secure using the stock hardware. Do not tighten at this point. **Special note: There is a "F" cut out in this bracket, the "F" will go towards the front of the vehicle and also if you are standing on the passenger side wheel well looking at the new passenger side differential relocation bracket, you should not be able to see the mounting hardware. This will help you make sure that the bracket is installed properly.**

41. With the help from a buddy, carefully lift the modified front differential back onto a pair of hydraulic floor jacks and move the hydraulic floor jacks back underneath the vehicle so that the newly modified front differential can be re-installed.

42. Locate (2) 9/16" x 1 3/4" bolts, (4) 1/2" USS flat washers and (2) 9/16" unitorque nuts from hardware bag 16965NB4. Carefully install the passenger side of the stock front differential to the previously installed passenger side differential drop bracket. Secure using the new 9/16" x 1 3/4" bolts and hardware. **Do not tighten at this point.** Also at this time, remove the hydraulic floor jack holding the passenger side of the differential ONLY. Make sure not to remove the hydraulic floor jack holding the driver side of the front differential at this time.

Photo # 52 / Photo # 53

43. Locate the new rear cross member. Also, locate the stock lower control arm rear mounting hardware that was removed in step # 25. Install the new rear cross member to the stock rear lower control arm pockets and secure using

the stock hardware. **Special note: Make sure to install the stock hardware from the front of the vehicle towards the rear of the vehicle. Do not tighten at this point.**

Photo # 54 / Photo # 55

44. Locate the new front cross member. Also, locate the stock lower control arm front mounting hardware that was removed in step # 25. Install the new front cross member to the stock front lower control arm pockets and secure using the stock hardware. **Special note: Make sure to install the stock hardware from the front of the vehicle towards the rear of the vehicle. Do not tighten at this point.**

Photo # 56

45. Carefully lower down on the hydraulic floor jack holding the driver side of the stock front differential until the front differential seats properly into the rear cross member and the newly installed driver side differential relocation bracket can be installed to the front cross member.

46. Locate the stock hardware that was removed from step # 33. Secure the newly installed front differential relocation bracket to the newly installed front cross member. Secure using the stock hardware. **Do not tighten at this point.**

Photo # 57

47. Locate the stock hardware that was removed from step # 26. Install the rear portion of the front differential into the tab on the newly installed rear cross member. Secure using the stock hardware. **Do not tighten at this point.**

Photo # 58

48. Carefully remove the hydraulic floor jack that is holding the driver side of the stock front differential.

49. Locate (2) 5/8" x 4 1/2" bolts, (2) 5/8" x 5 1/2" bolts, (8) 9/16" USS flat washers and (4) 5/8" unitorque nuts from hardware bag 16965NB5. Also, locate the stock lower control arms that were removed from step # 25. Working on the driver side, install the stock lower control arm into the newly installed front cross member and secure using the new 5/8" x 4 1/2" bolt and hardware. **Do not tighten at this point.** Install the stock lower control arm into the newly installed rear cross member and secure using the new 5/8" x 5 1/2" bolt and hardware. **Do not tighten at this point.** Repeat procedure on the passenger side.

Photo # 59

50. Using a hydraulic floor jack, carefully raise up on the front portion on the newly installed front cross member until the newly installed front cross member sits flush with the stock front cross member.

51. Locate (2) stock upper skid plate lower bolts that were removed from step # 6. Working on the driver side, secure the newly installed front cross member to the stock front cross member using the stock hardware. **Torque to 38 ft**

lbs. Special note: Make sure to use thread locker or lock tite. Repeat procedure on the passenger side. Carefully remove the hydraulic floor jack from under the front cross member.

Photo # 60 / Photo # 61

52. Move back to the stock and new hardware that is attaching the new passenger side differential relocation bracket to the stock location and the stock differential and add some thread locker or lock tite and torque the stock hardware to **75 ft lbs.** and the new 9/16" hardware to **85 ft lbs.**

Photo # 62

53. Locate the new 6" integrating skid plate. Also, locate (6) 1/2" x 1 1/2" bolts, (12) 7/16" USS flat washers and (6) 1/2" unitorque nuts from hardware bag 14959NB1. Install the new 4" integrating skid plate to the front and rear cross members and secure using the new 1/2" x 1 1/2" bolts and hardware. **Do not tighten at this point.**

Photo # 63

54. Working on the driver side, move back to the stock hardware attaching the new front cross member into the stock lower control arm pocket and add some thread locker or lock tite and torque to **105 ft lbs.** Repeat procedure on the passenger side.

Photo # 64

55. Working on the driver side, move back to the stock hardware attaching the new rear cross member into the stock lower control arm pocket and add some thread locker or lock tite and torque to **105 ft lbs.** Repeat procedure on the passenger side.

Photo # 65

56. Working on the driver side, move back to the stock hardware attaching the newly installed driver side differential relocation bracket to the newly installed front cross member and add some thread locker or lock tite and torque to **75 ft lbs.**

Photo # 66

57. Working on the driver side, move back to the stock hardware attaching the rear portion of the stock front differential to the newly installed rear cross member and add some thread locker or lock tite and torque to **75 ft lbs.**

Photo # 67

58. Move back to the new hardware attaching the new skid plate to the front and rear cross member and add some thread locker or lock tite on all (6) bolts and torque all (6) bolts to **70 ft lbs.**

Photo # 68 / Photo # 69

59. Reconnect the 4WD wiring to the front differential. Also, reconnect any other vent hoses and/or wiring that was connected to the stock front differential.

Photo # 70

60. Locate the stock front drive line hardware that was removed in step # 29. Re-install the stock front drive line to the stock front differential using the stock hardware. Make sure to use thread locker or lock tite and torque to **18 ft lbs.**

Photo # 71

61. Locate (2) poly bump stops from hardware bag 16965PL. Also, locate (2) 3/8" unitorque nuts and (2) 5/16" USS flat washers from hardware bag 16965NB1. Working on the driver side rear pocket of the newly installed rear cross member, secure the new poly bump stop using the new 3/8" hardware. Make sure to use thread locker or lock tite and torque to **28 ft lbs.** Repeat procedure on the passenger side.

Photo # 72 / Photo # 73

62. Locate the new driver side steering knuckle and the stock hub assembly. Also, locate the stock hardware for the upper control arm ball joint and the lower control arm ball joint that was removed in step # 22. Using the stock hardware, secure the new driver side steering knuckle and stock hub assembly to the stock upper control arm ball joint and the stock lower control arm ball joint using the stock hardware. Torque the stock upper control hardware to **74 ft lbs.** and the stock lower control arm hardware to **101 ft lbs.** Make sure to use thread locker or lock tite. Repeat procedure on the passenger side using the passenger side steering knuckle.

Photo # 74 / Photo # 75

Photo # 76 / Photo # 77

63. Locate the stock CV axles that were removed from step # 19. Working on the driver side, carefully install the stock CV axle back into the stock hub assembly. Repeat procedure on the passenger side.

64. Locate (2) axle half shaft spacers. Also, locate (12) 10 mm x 55 mm hex bolts and (12) 10 mm lock washers from hardware bag 16965NB1. Working on the driver side, install (1) new axle spacer between the stock front differential and the stock CV axle. Secure using the new 10 mm x 55 mm bolts and hardware. Make sure to use thread locker or lock tite and torque to **65 ft. lbs. Special note: Make sure that the stock axle is re-installed back into the stock location on the stock front differential. Refer to the scribe mark that was made in step # 17.** Repeat on the passenger side.

Photo # 78

65. Locate the stock hardware that connects the stock front axle to the stock hub assembly that was removed in step # 17. Working on the driver side, secure the stock front axle to the stock hub assembly using the stock hardware. Make sure to use thread locker or lock tite and torque to **112 ft. lbs.** Also, re-install the hub assembly center cap that was removed from step # 16. Repeat procedure on the passenger side.

Photo # 79

66. Working on the driver side, reconnect the stock ABS lines back together. Also reconnect all other stock mounting points on the stock ABS line. Repeat procedure on the passenger side.

Photo # 80

67. Locate the stock rotors that were removed in step # 22. Working on the driver side, install the stock rotor into the stock location. Repeat procedure on the passenger side.

68. Locate the stock brake caliper hardware that was removed in step # 14. Working on the driver side, re-install the stock brake caliper to the newly installed knuckle and secure using the stock hardware. Make sure to use thread locker or lock tite and torque to **76 ft. lbs.** Repeat procedure on the passenger side.

69. Locate the stock brake line hardware that was removed in step # 12. Working on the driver side, attach the stock brake line bracket to the stock upper control arm and secure using the stock hardware. Make sure to use thread locker or lock tite and torque to **18 ft lbs.** Now working on the inside of the newly installed driver side knuckle, reconnect the stock brake line bracket to the new driver side knuckle. Secure using the stock hardware. Make sure to use thread locker or lock tite and torque to **18 ft lbs.** Repeat procedure on the passenger side. **Special note: If need be, the stock bracket line bracket that wraps around the stock brake line may need to be opened up so that the brake line does not get kinked.**

Photo # 81 / Photo # 82

70. Working on the driver side and using a sawzall or a die grinder, carefully cut off the front corner of the stock front bump stop. This will allow clearance so the front shock does not contact the front corner of the stock front bump stop. **Special note: Make sure to check that there is clearance once the new shock is installed. If contact occurs, carefully cut more out of the front corner of the stock front bump stop.** Repeat procedure on the passenger side.

Photo # 83

71. Locate the stock shock and the stock upper shock hardware that was removed in step # 8. Working on the driver side, install the stock shock into the stock upper location and secure using the stock hardware. **Do not tighten at this point. Special note: When re-installing the stock shock back into the stock upper location, take special care not to damage the load sensor valve.** Repeat procedure on the passenger side.

72. Locate the new driver and passenger side front shock relocation bracket. Locate (4) MO2220 poly bushings from hardware bag 16965PL. Locate (2) S10074 crush sleeves from hardware bag 16965SL. Install the new poly bushings and crush sleeves into the new driver and passenger side front shock relocation brackets. **Special note: Make sure to use a lithium or moly base grease prior to inserting**

the new bushings and sleeves into the new driver side and passenger side front shock relocation brackets. This will increase the life of the bushing as well as prevent squeaking.

73. Locate the stock lower shock hardware that was removed in step # 8. Locate (2) 1/2" USS flat washers from hardware bag 16965NB4. Also, locate (2) SUW-916 u-bolt hardware washers from hardware bag 16965PL. Working on the driver side, install the new driver side shock relocation bracket into the stock shock location on the stock lower control arm. Secure using the stock hardware. **Do not tighten at this point. Special note: We want to install (1) 9/16" u-bolts washer as a spacer between the new bracket and the front of the stock location. Also, we want to use (1) 1/2" USS flat washer as a spacer between the new bracket and the rear of the stock location.** Repeat procedure on the passenger side.

74. Locate (2) 7/16" x 1 1/2" bolt, (4) 3/8" USS flat washers and (2) 7/16" unitorque nuts from hardware bag 16965NB2. Working on the driver side, push the new driver side shock relocation bracket towards the inside of the vehicle and using the driver side shock relocation bracket as a guide, drill a 7/16" hole into the stock lower control arm bump stop location. Secure the new driver side shock relocation bracket to the stock lower control arm using the new 7/16" x 1 1/2" bolt and hardware. **Do not tighten at this point.** Repeat procedure on the passenger side.

Photo # 84

75. Move back to the stock hardware that was installed in step # 73 and add some thread locker or lock tite and torque to **85 ft lbs.** Move back to the new 7/16" x 1 1/2" bolts that were installed in step # 73 and add some thread locker or lock tite and torque to **42 ft lbs.**

76. Locate (2) 9/16" x 3" bolts, (4) 1/2" USS flat washers and (2) 9/16" unitorque nuts from hardware bag 16965NB4. Working on the driver side, re-install the stock shock to the newly installed shock relocation bracket and secure using the new 9/16" x 3" bolt and hardware. Make sure to use thread locker or lock tite and torque to **95 ft lbs.** Repeat procedure on the passenger side. **Special note: After the installation of the stock shock, check to make sure that there is proper clearance between the stock shock and the stock bump stop bracket. If there is contact between the stock shock and the stock bump stop bracket, carefully cut off the corner of the stock bump stop bracket for proper shock clearance.**

Photo # 85

77. Working on the driver side, torque the upper stock shock hardware to **18 ft lbs.** Now carefully re-install the stock load sensor valve to the top of the stock shock. Repeat procedure on the passenger side.

78. Locate the stock actuator rods that were removed in step # 9. Working on the driver side, install the stock

actuator into the stock location. Repeat procedure on the passenger side.

Photo # 86

79. Locate (2) 1/2" x 15" bolts and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Locate (2) new sway bar end links from hardware bag 16965SL. Also, locate (8) sway bar end link bushings and (8) sway bar end link washers from hardware bag 16965PL. Working on the driver side, install the new sway bar end link and hardware into the stock location. **Do not tighten at this point.** This bolt will be torqued to proper torque settings once the weight of the vehicle is on the ground. Repeat procedure on passenger side.

Photo # 87

80. Locate the stock outer tie rod ball joint hardware that was removed from step # 11. Working on the driver side, install the stock outer tie rod to the new steering knuckle using the stock hardware. Make sure to use thread locker or lock tite and torque to **53 ft. lbs.** **Special note: The new steering knuckle has a reverse taper on it where the stock outer tie rod mounts to it, make sure to install the outer tie rod the proper way. The stock outer tie rod nut will now be installed on the bottom side of the new steering knuckle.** Repeat procedure on the passenger side.

Photo # 87

81. Locate (4) new torsion bar drop plates. Locate (2) 9/16" x 3 1/2" bolts, (4) 1/2" USS flat washers and (2) 9/16" unitorque nuts from hardware bag 16965NB4. Working on the driver side, install the new torsion bar drop plates to the stock torsion bar cross member location and secure using the new 9/16" x 3 1/2" bolt and hardware. **Do not tighten at this point.** Repeat procedure on the passenger side. **Special note: When installing these brackets, the bend of the bracket will go towards the inside of the vehicle then out towards the outside of the vehicle.**

82. Locate the stock torsion bars that were removed from step # 5. Refer to the marks that were made in step # 3. This will allow you to re-install the stock torsion bars back into the stock location. **Example: Driver vs. Passenger and Front vs. Rear.** Working on the driver side, slide the stock torsion bar back into the stock rear lower control arm. Slide the stock torsion bar far enough forward so that the stock torsion bar cross member can be re-installed. Repeat procedure on the passenger side.

83. Locate the stock torsion bar cross member that was removed in step # 4. Working on the stock torsion bar cross member, remove the stock nut that is tack welded to the back side of the torsion bar cross member. Make sure to remove from both the driver and the passenger side of the stock torsion bar cross member. Set the torsion bar cross member aside for later re-installation.

84. Locate (2) 9/16" x 3 1/2" bolt, (4) 1/2" USS flat washers

and (2) 9/16" unitorque nuts from hardware bag 16965NB4. Locate (2) S10020 crush sleeves from hardware bag 16965SL. Also, locate the newly modified stock torsion bar cross member. Working on the driver side, install the stock torsion bar cross member to the newly installed torsion bar drop plates and secure using the new 9/16" x 3 1/2" bolt, hardware and crush sleeve. **Do not tighten at this point.** On the rear tab of the stock torsion bar cross member, you will notice that this hole is larger in diameter than the front hole, the new crush sleeve outside diameter will be small enough for the tab of the stock torsion bar cross member to slide over the sleeve. Repeat procedure on the passenger side. Move back to the upper and lower mounting bolts and add some thread locker or lock tite and torque the upper and lower mounting bolt to **95 ft lbs.**

Photo # 88

85. Locate the stock torsion bar keys that were removed in step # 3. Working on the driver side, install the stock torsion bar key back into the stock location in the stock torsion bar cross member. Slide the stock torsion bar back into the previously installed torsion bar key. Repeat procedure on the passenger side. **Special note: Make sure that the torsion bars are installed in the stock location in the stock lower control arm and the stock torsion bar key. Refer to the marks that were scribed in step # 3.**

86. Locate the torsion bar adjusting blocks and hardware that was removed from step # 2. Working on the driver side, attach the torsion bar removing tool to the stock torsion bar cross member, making sure that the unloading bolt in the center of the torsion bar removing tool is in the small divot of the stock torsion bar key. Adjust the torsion bar key up high enough so that the stock small metal adjusting block and bolt can be re-installed back into the stock location. Remove the torsion bar removal tool from the stock torsion bar cross member. **Special note: Set the driver and the passenger side torsion bar bolt so that there is 3/4" of thread showing between the head of the bolt and the adjusting block.** Repeat on the passenger side.

If the vehicle that you are working on has the stock transfer case bolted to the bottom of the stock frame rail, please follow steps 87 — 92.

If the vehicle that you are working on has the stock transfer case bolted to brackets that are welded to the inside of the stock frame rail, please follow steps 93 — 97.

87. Locate (2) 1/2" x 3 1/2" bolts, (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Working on the driver side, install the new lateral compression arm into the lateral compression arm mounts located on the previously installed rear cross member. Secure using the new 1/2" x 3 1/2" bolts and hardware. **Do not tighten at this point.** Let the new lateral compression arm hang. Repeat procedure on the passenger side.

88. Working on the driver side, remove and discard the stock bolt and hardware that connects the stock transfer case cross member to the stock transfer case cross member frame support bracket.

89. Locate (2) new rear lateral compression arm mounts. Locate (2) 1/2" x 2 1/2" bolts, (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Working on the driver side, secure the new lateral compression arm mount to the stock transfer case cross member using the new 1/2" x 2 1/2" bolt and hardware. The mount will be located where you removed the stock bolt in step # 88. **Special note: Make sure that the new rear lateral compression mount is parallel to the stock frame rail.** Lift the new lateral compression arm up to see if it will be able to mount to the new rear lateral compression arm mount, if the hole lines up, torque to **70 ft lbs.** If the holes do not line up, slide the new rear lateral compression arm mount forward or rearward so that the new lateral compression arm will mount up to the new rear lateral compression arm mount. Make sure to use thread locker or lock tite. Repeat procedure on the passenger side. **Special note: The passenger side rear lateral compression arm mount will be mounted opposite of the driver side rear lateral compression arm mount.**

Photo # 89 / driver side shown

90. Working on the driver side, using the newly installed rear lateral compression arm bracket as a guide, carefully drill a 5/16" hole into the stock cross member. **Special note: There are (2) 3/8" holes in the new rear lateral compression arm mounting bracket, use the rear hole as a guide. The stock transfer case cross member is boxed in, so you only need to drill through the bottom wall of the cross member. Make sure not to drill all the way through the stock transfer case cross member.** Repeat procedure on the passenger side, using the rear hole in the new rear lateral compression arm bracket as a guide.

Photo # 89 / driver side shown

91. Locate (2) 3/8" x 3/4" self threading bolt from hardware bag 16965NB1. Working on the driver side, install the new 3/8" x 3/4" self threading bolt into the previously drilled 5/16" hole. Torque to **28 ft lbs.** Make sure to use thread locker or lock tite. Repeat procedure on the passenger side.

92. Locate (2) 1/2" x 3 1/2" bolts, (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Working on the driver side, install the new lateral compression arm to the previously installed rear lateral compression arm mount and secure using the new 1/2" x 3 1/2" bolts and hardware. Make sure to use thread locker or lock tite. Torque to **85 ft lbs.** Move back to the new 1/2" x 3 1/2" bolts holding the new lateral compression arms to the newly installed rear cross member and add some thread locker or lock tite and torque to **85 ft lbs.**

Photo # 90 / front location

Photo # 91 / driver side rear location
Photo # 92 / passenger side rear location

If the vehicle that you are working on has the stock transfer case bolted to the bottom of the stock frame rail, please skip to step # 98.

93. Locate (2) 1/2" x 3 1/2" bolts, (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Working on the driver side, install the new lateral compression arm into the lateral compression arm mounts located on the previously installed rear cross member. Secure using the new 1/2" x 3 1/2" bolts and hardware. **Do not tighten at this point.** Let the new lateral compression arm hang. Repeat procedure on the passenger side.

94. Locate (2) new rear lateral compression arm mounts. Also, locate (2) 1/2" x 3 1/2" bolts from hardware bag 16965NB3. Working on the driver side, secure the previously installed lateral compression arm to the new rear lateral compression arm bracket using the 1/2" x 3 1/2" bolt. For now, just use the bolt to hold the bracket to the lateral compression arm. Swing the lateral compression arm back towards the rear of the vehicle until the new rear lateral compression arm bracket can be mounted to the stock transfer case cross member. **Special note: Once the new rear lateral compression arm bracket is attached to the stock transfer case cross member and the new lateral compression arm is secured to the new rear lateral compression arm bracket, the new lateral compression arm should be parallel to the stock frame rail.** Holding the new rear lateral compression arm bracket to the bottom side of stock transfer case cross member, remove the new 1/2" x 3 1/2" bolt that is holding the lateral compression arm to the new rear lateral compression arm bracket. Set the 1/2" x 3 1/2" bolt aside for later re-installation. Let the new lateral compression arm hang. Using the round holes in the new rear lateral compression arm mount as guides, scribe 2 marks on the bottom side of the stock transfer case cross member. Repeat procedure on the passenger side. Set the new rear lateral compression arm mount brackets aside for later re-installation.

95. Working on the driver side, carefully drill (2) 5/16" holes into the bottom side of the stock transfer case cross member. Repeat procedure on the passenger side.

96. Locate the new rear lateral compression arm bracket. Also, locate (4) 3/8" x 3/4" self threading bolts from hardware bag 16965NB1. Working on the driver side, secure the new rear lateral compression arm brackets to the bottom side of the stock transfer case cross member using the new 3/8" x 3/4" self threading bolts. Torque to **28 ft lbs.** Make sure to use thread locker or lock tite. Repeat procedure on the passenger side.

Photo # 93 / Driver side shown

97. Locate the (2) 1/2" x 3 1/2" bolts that were used in step

94. Also, locate (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Working on the driver side, install the new lateral compression arm to the previously installed rear lateral compression arm mount and secure using the new 1/2" x 3 1/2" bolts and hardware. Make sure to use thread locker or lock tite. Torque to **85 ft lbs.** Move back to the new 1/2" x 3 1/2" bolts holding the new lateral compression arms to the newly installed rear cross member and add some thread locker or lock tite and torque to **85 ft lbs.**

Photo # 90 / front location

Photo # 94 / driver side rear location

Photo # 95 / passenger side rear location

98. Re-install the tires and wheels and carefully lower the vehicle to the ground.

99. Check and double check to make sure that all steps were performed properly and check again.

100. There are still a couple of steps that need to be completed on the front end but these steps will not be completed until the rear end installation is completed and the weight of the vehicle is on the ground. These steps include the tightening of the front sway bar end links and the tightening of the new hardware that connects the stock lower control arms to the newly installed front and rear cross member.

Front-end installation complete!

Rear-end installation:

101. To begin installation, block the front tires of the vehicle so that the vehicle is stable and can't roll forward. Safely lift the rear of the vehicle and support the frame with a pair of jack stands. Place a jack stand on both the driver and passenger side. Next, remove the wheels and tires from both sides.

102. Place a pair of hydraulic floor jacks under the rear axle and raise up on both hydraulic floor jacks at the same time until they come into contact with the rear axle.

103. Working on the driver side, remove the stock hardware that connects the stock sway bar end link to the stock location. Save the stock upper sway bar mounting hardware for later re-installation. The stock sway bar end link and lower hardware may be discarded. Repeat procedure on the passenger side.

104. Working on the driver side, carefully remove the ball joint coupler from the stock shock actuator rod. Carefully remove the stock actuator rod from the top and bottom ball joint caps. The rear stock actuator can be discarded. Repeat procedure on the passenger side.

105. Working on the driver side, remove the stock rear lower shock mounting bolt from the stock rear location and

save the stock hardware for later re-installation. **Special Note: The stock shock will be re-installed. The stock upper mounting point does not need be removed, let the stock shock hang.** Repeat procedure on passenger side.

106. Working on the driver side, remove the stock bolt that connects the stock rear track bar to the stock rear track bar location. Save the stock hardware for later re-installation.

107. Working on the driver side, scribe a mark on the stock rear coil spring and another directly across on the stock coil spring pocket. **This will allow you to re-install the stock coil spring back into the stock location.** Repeat procedure on passenger side. Carefully lower down on both hydraulic floor jacks at the same time about 4" - 4.5". **Special Note: Take special care not to kink or over extend any brake lines and/or hoses.** Remove the stock driver and passenger side coil springs and set aside for later re-installation.

108. Locate (2) rear coil spring spacer. Working on the driver side, hold the new coil spring spacer into the upper coil spring pocket. With a marker, using the new bracket as a guide, scribe (3) marks on the stock upper coil spring pocket. Remove the new coil spring spacer and set aside for later re-installation. Repeat procedure on the passenger side.

109. Working on the driver side, carefully drill 5/16" holes into the stock upper coil spring pocket where the marks were scribed in step # 108.

110. Locate (6) 3/8" x 3/4" self threading bolts from hardware bag 16965NB1. Working on the driver side, install the new coil spring spacer into the stock upper pocket and secure using the new 3/8" x 3/4" self threading bolts. Make sure to use thread locker or lock tite. Torque to **32 ft lbs.** Repeat procedure on the passenger side.

111. Locate the new rear track bar relocation bracket. Also, locate (1) 9/16" x 3 1/2" bolt, (2) 1/2" USS flat washers and (1) 9/16" unitorque nut from hardware bag 16965NB4. Also, locate (1) 1/2" x 1 1/2" bolt, (2) 7/16" USS flat washers and (1) 1/2" unitorque nut from hardware bag 16965NB3. Install the new track bar relocation bracket into the stock track bar location and secure using the new 9/16" x 3 1/2" bolt and hardware. **Do not tighten at this point.** Make sure that the new track bar relocation bracket is sitting square in the stock pocket. Using the new track bar relocation bracket as a guide, carefully drill a 1/2" hole into the stock track bar bracket. Secure the new track bar relocation bracket to the new 1/2" hole in the stock track bar bracket using the new 1/2" x 1 1/2" bolt and hardware. Make sure to use thread locker or lock tite add torque the new 1/2" bolt to **85 ft lbs.** Move back to the new 9/16" x 3 1/2" bolt and add some thread locker or lock tite and torque to **112 ft lbs.**

112. Locate the stock track bar hardware that was removed

from step # 106. Secure the stock track bar to the newly installed track bar relocation bracket and secure using the stock hardware. Make sure to use thread locker or lock tite. Torque the stock bolt to **108 ft lbs.** **Special Note: If you are not able to line up the hole on the track bar and the new track bar relocation bracket, you may have to perform this step once the weight of the vehicle is on the ground.**

Photo # 96

113. Locate (2) new rear shock relocation brackets. Locate (2) 9/16" x 3" bolts, (4) 1/2" USS flat washer and (2) 9/16" unitorque nuts from hardware bag 16965NB4. Locate (2) 7/16" x 1 1/4" bolt, (4) 3/8" USS flat washers and (2) 7/16" unitorque nuts from hardware bag 16965NB2. Also, locate (2) S10019 crush sleeves from hardware bag 16965SL. Working on the driver side, install the new shock relocation bracket into the stock location and secure using the new 9/16" x 3" bolt, hardware and (1) S10019 crush sleeve. **Do not tighten at this point.** Make sure that the new rear shock relocation bracket is sitting flush with the stock shock bracket, carefully drill a 7/16" hole in the bottom of the stock shock bracket and the newly installed shock relocation bracket. Secure the shock relocation bracket to the stock shock bracket using the new 7/16" x 1 1/4" bolt and hardware. Move back the new 9/16" bolt and add some thread locker or lock tite and torque to **112 ft lbs.** Now move back to the new 7/16" hardware and add some thread locker or lock tite and torque to **35 ft lbs.** Repeat procedure on the passenger side.

Photo # 97

114. Locate the stock rear coil springs that were removed from step # 107. Working on the driver side, re-install the stock rear coil spring into the stock lower coil spring pocket. Repeat procedure on the passenger side. **Special note: make sure to re-install the stock coil spring back into the stock location, refer to the marks that were scribed in step # 107.** Carefully raise up on both hydraulic floor jacks at the same time until the stock coil springs seats properly with the newly installed upper coil spring spacers.

115. Locate the stock lower shock mounting hardware that was removed from step # 105. Working on the driver side, install the lower portion of the stock shock into the newly installed lower shock relocation bracket. Secure using the stock hardware. Make sure to add some thread locker or lock tite and torque to **112 ft. lbs.** Repeat procedure on the passenger side.

Photo # 98

116. Carefully remove the (2) hydraulic floor jacks from under the rear differential.

117. Locate (2) new actuator rods from hardware bag 16965NB1. Working on the driver side, carefully install the new actuator rod into the stock rear location by inserting the actuator rod into the bottom ball joint cap and then into the top. Repeat procedure on the passenger side.

Photo # 99

118. Locate (2) new rear sway bar end links. Locate (8)

MO2220 poly bushings from hardware bag 16965PL. Also, locate (4) S10026 sleeves from hardware bag 16965SL. Install the new poly bushings and sleeves into each end of the new rear sway bar end links. **Special Note: Make sure to use a lithium or moly base grease prior to inserting the new bushings and sleeves into the new rear sway bar end links. This will increase the life of the bushing as well as prevent squeaking.**

119. Locate (2) 1/2" x 2 1/2" bolts, (4) 7/16" USS flat washers and (2) 1/2" unitorque nuts from hardware bag 16965NB3. Also, locate the stock upper sway bar mounting hardware that was removed in step # 103. Working on the driver side, install the new sway bar end link into the stock uppr location and secure using the stock hardware. Now install the lower portion of the new sway bar end link to the stock sway bar and secure using the new 1/2" x 2 1/2" bolt and hardware. **Do not tighten at this point.** Repeat procedure on the passenger side. Once both new sway bar end links are secure to the stock location add some thread locker or lock tite to the new and stock bolts and torque to **85 ft lbs.** **Special Note: If you are not able to connect the new rear sway bar end link to the stock location, the weight of the vehicle may need to be on the ground. If this is the case, perform this step once the tires have been installed and the vehicle is on the ground.**

Photo # 100 / Photo # 101

120. Locate (1) BLR01, (1) 5/16" x 1" bolt (2) 1/4" USS flat washers and (1) 5/16" unitorque nuts from hardware bag 16965PL. Working on the driver side, remove the emergency brake line bracket from the stock frame rail. Using the stock bolt, secure the BLR01 to the stock location. Make sure to use thread locker or lock tite and torque the stock bolt to **12 ft lbs.** Now, install the stock emergency brake cable bracket to the newly installed BLR01 and secure using the new 5/16" x 1 1/2" bolt and hardware. Make sure to use thread locker or lock tite and torque to **18 ft lbs.**

Photo # 102

121. Install the tires and wheels and carefully lower the vehicle to the ground.

122. If you were not able to attach the stock track bar to the new track bar relocation bracket in step # 112, perform this step now that the weight of the vehicle is on the ground.

Photo # 96

123. If you were not able to attach the new sway bar end links to the stock location in step # 119, perform this step now that the weight of the vehicle is on the ground.

Photo # 100 / Photo # 101

124. Install the tires and wheels and carefully lower the vehicle to the ground.

Step # 125 and # 126 needs to be performed with the weight of the vehicle on the ground.

125. Working on the driver side, move back to the new 5/8" hardware attaching the stock lower control arms to the newly

installed front and rear cross members and add some thread locker or lock tite and torque to **125 ft lbs.** Repeat procedure on the passenger side.

126. Working on the driver side, move back to the newly installed sway bar end link bolts and add some thread locker or lock tite and torque to **55 ft lbs.** Repeat procedure on the passenger side.

127. Check and double check to make sure that all steps were performed properly. And then check them again.

Congratulations, installation complete!

Special note: After the completion of the installation, Tuff Country EZ-Ride Suspension recommends taking the vehicle to an alignment shop and having a proper front end alignment performed.

Tuff Country EZ-Ride Suspension recommends that a complete re-torque is done on all bolts associated with this suspension system. It is the customers responsibility to make sure that a re-torque is performed on all hardware associated with this suspension system after the first 100 miles of installation. It is also the customers responsibility to do a complete re-torque after every 3000 miles or after every off road use. Neglect of following these steps could cause brackets to come loose and cause serious damage to the suspension system and to the vehicle.

Tuff Country EZ-Ride Suspension packages (2) sets of instruction sheets with this box kit. (1) is for the installer and (1) is for the customer. The (1) for the customer has some post installation procedure literature and it is the installers responsibility to make sure that the customer receives a copy of the installation manual along with the literature.

If you have any questions or concerns, please feel free to contact Tuff Country or your local Tuff Country dealer.

Special post installation procedure: Tuff Country EZ-Ride Suspension highly recommends adding a minimum of 1 pint, but no more that 1 1/2 pints, of proper front differential fluid into the front differential. To achieve this, you may have to fill the differential with it on its side or you may have to insert the fluid through the vend tube opening. On occasion, the customer may find burping of fluid coming out of the front vent tube.



Photo # 1



Photo # 2



Photo # 3



Photo # 4



Photo # 5



Photo # 6



Photo # 7



Photo # 8



Photo # 9



Photo # 10



Photo # 11



Photo # 12




Photo # 13




Photo # 14



Photo # 15



Photo # 16



Photo # 17



Photo # 18



Photo # 19



Photo # 20



Photo # 21



Photo # 22



Photo # 23



Photo # 24



Photo # 25



Photo # 26



Photo # 27



Photo # 28



Photo # 29



Photo # 30



Photo # 31



Photo # 32



Photo # 33



Photo # 34



Photo # 35



Photo # 36



Photo # 37



Photo # 38



Photo # 39




Photo # 40




Photo # 41



Photo # 42



Photo # 43



Photo # 44



Photo # 45




Photo # 46



Photo # 47




Photo # 48




Photo # 49



Photo # 50



Photo # 51




Photo # 52




Photo # 53




Photo # 54



Photo # 55



Photo # 56



Photo # 57



Photo # 58




Photo # 59



Photo # 60



Photo # 61



Photo # 62



Photo # 63




Photo # 64




Photo # 65



Photo # 66




Photo # 67



Photo # 68




Photo # 69



Photo # 70




Photo # 71



Photo # 72



Photo # 73



Photo # 74



Photo # 75



Photo # 76



Photo # 77



Photo # 78



Photo # 79




Photo # 80




Photo # 81



Photo # 82



Photo # 83



Photo # 84



Photo # 85



Photo # 86



Photo # 87



Photo # 88



Photo # 89




Photo # 90




Photo # 91




Photo # 92



Photo # 93



Photo # 94



Photo # 95




Photo # 96



Photo # 97



Photo # 98



Photo # 99



Photo # 100



Photo # 101



Photo # 102




DSDIFF-01 (1)
DS differential relocation bracket



16955-06 (1)
PS differential relocation bracket



16965-05 (1)
DS front shock relocation bracket



16965-06 (1)
PS front shock relocation bracket



16965-12 (2)
Rear coil spring spacers



16965-13 (2)
DS & PS rear chock relocation bracket



14965-27 (4)
Torsion bar drop shims



16965-11 (1)
Rear track bar relocation bracket




16955-01M (1)
Driver side knuckle




16955-02M (1)
Passenger side knuckle



16955-16 (1)
Front cross member



16955-17 (1)
Rear cross member



16955-18 (1)
6" integrating skid plate