



# TYGER®

## FENDER FLARE

TG-FF8F4168

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ONLY FOLLOW THE APPROVED INSTALLATION ACCORDING TO THESE WRITTEN INSTRUCTIONS. FAILURE TO DO SO MAY CAUSE DAMAGE TO YOUR VEHICLE AND INVALIDATE THE WARRANTY.

### PRIOR TO INSTALLATION:

- Remove contents from box. Verify all parts are present and free from any defects or damage.
- Make sure installation is done on a non-abrasive surface to avoid scratching the flare surface.
- Verify the fit of each flare to the vehicle body to ensure you have the correct flares for your vehicle.
- Remove existing decals and mud flaps on the vehicle that may interfere with flare installation.
- Do not use any harsh abrasive detergent to clean the flare.

### PAINTING

Painted flares cannot be returned. Test fit before painting. We are not responsible for any costs that may incur if flares were painted without test fitting.

- Clean surface to be painted with a good grade degreaser. Do not use lacquer thinner or any solvent based product.
- Wipe flare surface completely dry with a tack rag prior to paint.
- Application of plastic adhesion promoter for PP plastic as per your paint system manufacturer's recommendations is required.
- Use a high quality enamel or polyurethane automotive paint to paint the flares.
- Not recommend to paint the edge trim, but if desired use a flex additive.


### WARNING

Dirt or debris may become lodged between flares and vehicle's fenders causing scratching and paint wear from vehicle vibration. TYGER is not responsible for any damage, and installation is done with buyer's understanding that this damage may potentially occur.


### SAFETY INFORMATION

- Before driving, ensure that flare is properly secured to vehicle.
- Do not use automatic "brush-style" car wash.
- Periodically check all components for tightness.

### Tools Required



### Hardware Included




V200720

## EDGE TRIM INSTALLATION


- Peel 2 inches of red backing away from one end of Edge Trim **[A]** .
- Apply Edge Trim over top edge of flare with adhesive side contacting inside edge of flare.
- Press Edge Trim into place and apply thumb pressure to ensure good adhesion, pull away red backing as you work your way around flare edge in one-foot increments. (Fig 1)

**NOTE:** Do not stretch Edge Trim during application.



## DECORATIVE RIVET INSTALLATION

- Install a Torx Bolt **[B]** with a Washer **[C]** through each of the top holes around the flare and secure using a Nylock Nut **[D]** on the other side. Tighten using a socket wrench and the supplied Torx Bit **[E]**. Do not overtighten as this may damage the flare. (Fig 2)




**IMPORTANT:** Do not drill holes to the vehicle body as rivets are decorative and fasten only to the flare. Do not attempt to use the bolts to fasten flare to vehicle body.


## EXTRA NOTES

- All exposed fasteners and bare metal should be treated with rust resistant paint before installing flares. Spray inner fender wells with undercoating after flare installation.
- Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- For vehicle with large tires may require lowering bump stops and/or installing steering stops to prevent tire from contacting flare.


## Front Passenger Side Installation




**STEP 1:** With the indicated tools, remove the corresponding 7 factory screws and keep for later use.




**STEP 2:** With a grease pencil, mark 1 location as indicated using hole in flare as guide.




**STEP 3:** Stick a supplied Tab [F] over the mark made in Step 2, and wrap the Tab around the metal lip. Then, slide a Long U-clip [G] over the Tab.




**STEP 4:** Slide 3 supplied U-clips [H] onto the right inner bracket.  
NOTE: Right Inner Bracket has 'RR' marked on it.




**STEP 5:** Hold up the right inner bracket to the fender well while aligning the 3 holes in the bracket with vehicle's top 3 factory holes.




**STEP 6:** With a 7/32" socket wrench, reinstall 3 factory screws to secure the inner piece to the fender well.



**STEP 7:** Hold flare in position, install 3 supplied PH Truss Screws [1] through holes in flare and into holes in clips on the inner piece installed in Step 4. Do not tighten.




**STEP 8:** With the indicated tools above, reinstall the factory screws removed in Step 1.




**STEP 9:** With a PH Screwdriver, install a PH Truss Screw [1] through hole in flare and into clips installed in Step 3.


## Rear Passanger Side Installation




**STEP 10:** Remove factory screw from bottom rear of fender well.




**STEP 11:** Hold flare in position. With a grease pencil, mark 5 locations using holes in flare as guide. Then, remove flare.




**STEP 12:** Stick the supplied Tabs [F] over the 4 mark locations indicated in Step 13, and wrap the Tabs around the metal lip. Then, slide a Long U-clip [G] over each Tab.




**STEP 13:** Locations for Tab and Long U-clips installation.




**STEP 14:** Stick a supplied Mylar Tab [J] over the last remaining mark indicated in Step 15. Then slide a supplied S-clip [K] over the Mylar Tab.




**STEP 15:** Location for Mylar Tab and S-clip installation.





**STEP 16:** Reposition flare, install 4 supplied PH Truss Screws [I] through holes in flare and into the Long U-clips installed in Step 12.




**STEP 17:** Install a supplied PH Metal Screw [L] through hole in flare and into S-clips installed in Step 14.



**STEP 18:** Install a supplied Plastic Retainer [M] into hole in flare and vehicle's factory hole.




**STEP 19:** If needed use supplied tool [N] to trim outer edge (Fig 3) and inner edge (Fig 4) by inserting tool ends then sliding around the entire edge trims from one end to the other as shown in above pictures.




Passenger side installation is completed. (Repeat the same steps on driver side installation.)

# FITMENT OR GAP ISSUE?



# SOLUTION!



\*In winter, heat gun or hair dryer may be used instead.