

## **WARN Industrial Hoist**

| Model       | Part Number | Motor Type                                    |
|-------------|-------------|---|
| DC2000 (MF) | 85190       | DC Electric<br>24 Volt<br>Permanent<br>Magnet |



The DC2000 hoist combines a powerful permanent magnet DC motor with robust sealing and our proven 3-stage all metal geartrain. Permanent grease lubrication means years of trouble free service. All WARN hoists incorporate an automatic mechanical brake that holds full rated load. The durable powder coated finish stands up to the elements and looks great. The DC2000 hoist is built on a compact midsize framed with integrated tie bars that's easy to install. Controls and accessories available separately.

#### **Accessories**

| Description:                              | Part Number |
|---|-------------|
| Control Pack-24V                          | 63752       |
| Contactor Only-24V (Standard bracket)     | 34968       |
| Contactor Only-24V (w/ bracket for cover) | 34974       |
| Contactor Cover (with remote plug)        | 36648       |
| Contactor Cover (no plug)                 | 35169       |
| Remote Control Only                       | 88528       |

\*12 Volt model shown

| Engineering Data                                    |                |             |  |  |  |
|---|----------------|-------------|--|--|--|
| Rated Capacity:                                     | 2000 lbf       | 907 kgf     |  |  |  |
| Drum Barrel Diameter:                               | 4.25 in        | 108 mm      |  |  |  |
| Drum Flange Diameter:                               | 6.25 in        | 159 mm      |  |  |  |
| Distance Between Flanges:                           | 4.5 in         | 114 mm      |  |  |  |
| Recommended Maximum Wire Rope Diameter:             | 1/4 in         | 6.4 mm      |  |  |  |
| Recommended Minimum Wire Rope Breaking Strength:    | 7000 lbf       | 3175 kgf    |  |  |  |
| Approximate Shipping Weight:                        | 40.0 lb        | 18.1 kg     |  |  |  |
| Duty Cycle (intermittent per SAE J706 section 6.2): | N/A ft         | N/A m       |  |  |  |
| Mounting Bolt Torque:                               | 32 - 34 ft*lbf | 43 - 46 N*m |  |  |  |
| Maximum Layers of Wire Rope:                        | 2              |             |  |  |  |
| Gear Reduction:                                     | 261            |             |  |  |  |
| Brake Type:   | Automa         | tic Cone    |  |  |  |
| Contactor/Remote Type:                              | Not In         | cluded      |  |  |  |

Not Included



Viewed from Motor End

### Standards Compliance

- 1. CE Machinery Directive 98/37/EC and 2006/42/EC
- 2006/42/EC 2. - CE Electromagnetic Compatibility 2004/108/EC
- 3. ASME B30.5


| Performance By Lay |
|--------------------|
|--------------------|

| · ·············· |             |     |                    |        |               |    |      |   |
|------------------|-------------|-----|--------------------|--------|---------------|----|------|---|
| Drum Layer       | Line Load * |     | No Load Line Speed |        | Drum Capacity |    |      |   |
| Diulii Layei     | lbf         | kgf | kN                 | ft/min | m/min         | ft | m    | 1 |
| 1                | 2000        | 907 | 8.9                | 14.5   | 4.4           | 20 | 6.1  | ] |
| 2                | 1800        | 816 | 8.0                | 16.1   | 4.9           | 43 | 13.1 | 7 |
|                  |             |     |                    |        |               |    |      | 3 |
|                  |             |     |                    |        |               |    |      | 1 |
|                  |             |     |                    |        |               |    |      | 1 |

<sup>\*</sup> Never exceed the Rated Capacity. Installation of a Rated Capacity Limiter is recommended.

#### First Layer Performance

| Line I | _oad | Current Draw | Draw Line Speed |       | Duty Cycle |  |
|--------|------|--------------|-----------------|-------|------------|--|
| lbf    | kgf  | Amps         | ft/min          | m/min | min/10min  |  |
| 0      | 0    | 6            | 14.5            | 4.4   | Continuous |  |
| 400    | 181  | 15           | 14.4            | 4.4   | Continuous |  |
| 800    | 363  | 25           | 14.0            | 4.3   | Continuous |  |
| 1200   | 544  | 34           | 13.6            | 4.1   | 6.8        |  |
| 1600   | 726  | 44           | 13.2            | 4.0   | 4.6        |  |
| 2000   | 907  | 54           | 12.8            | 3.9   | 3.4        |  |
|        |      |              |                 |       |            |  |





60 (Y) 45 0 30 0 400 800 1200 1600 2000 Line Load (lbf)




# **WARN Industrial Hoist**

| Model       | Part Number | Motor Type                                    |
|-------------|-------------|---|
| DC2000 (MF) | 85190       | DC Electric<br>24 Volt<br>Permanent<br>Magnet |







Units are given in inches [millimeters], unless otherwise specified

| Recommended Mounting (Always Observe Correct Drum Rotation) |                                     |                                     | Electrical System Specifications  |
|---|-------------------------------------|-------------------------------------|---|
| Pull from bottom of hoist                                   | Pull from bottom of hoist           | Pull from top of hoist              | See Electrical Cable Gauge Size Chart for cable sizing  |
|   | <b></b> I                           | I                                   | All electrical connections must be clean and tight  |
|   |                                     |                                     | Electrical System Wiring Schematic Hoist provided without electrical controls. See accessories of front page for control kits.  Power IN (Hoisting)- Connect motor terminal #2 to positive. Connect motor terminal #1 to negative (Ground). |
| Feet down Pull from top of hoist                            | Feet forward Pull from top of hoist | Feet forward Pull from top of hoist | Power OUT (Lowering)- Connect motor terminal #1 to positiv Connect motor terminal #2 to negative (Ground).  |
|   |                                     |                                     | Notes:  |
| Feet down without angle brace                               | Feet down with angle brace          | Angle Braces Only                   |   |