



AUTOMOTIVE PRODUCTS, INC.

# INSTALLATION INSTRUCTIONS

## RUNNING BOARD


ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	2	RUNNING BOARDS	1/2" SOCKET
2,3	2	FRONT MOUNTING BRACKETS (2) DRIVERS SIDE, (3) PASSENGER SIDE	13MM SOCKET
4	4	REAR MOUNTING BRACKETS	RATCHET
5	12	M8 HEX HEAD BOLTS	TORQUE WRENCH
6	12	M8 FLAT WASHERS	
7	12	M8 LOCK WASHERS	
8	6	3/8" FLAT WASHERS	
9	12	5/16" SQUARE HEAD BOLTS	
10	12	5/16" FLAT WASHERS	
11	12	5/16" NYLOCK NUTS	
12	2	M8 WIRE NUTS	

1. Remove all contents from box, verify all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.
2. Starting from underneath the drivers side of the vehicle, behind the front wheel locate the two threaded holes located in the rocker panel of the vehicle. Take the drivers side front mounting bracket and attach to the threaded holes using (2) M8 hex head bolts, (2) M8 lock washers, and (2) M8 flat washers. (fig 1). Do not fully tighten at this time.
3. Move to the center of the vehicle and locate the two threaded holes in the vehicle see fig 2, attach the drivers side center rear mounting bracket to the threaded holes using (2) M8 hex head bolts, (2) M8 lock washers, and (2) M8 flat washers (fig 2). Do not fully tighten at this time.
4. Move to the rear of the vehicle, there will be one threaded hole in the frame. Next take (1) M8 wire nut and place it through the large hole located in the frame (fig 3). Attach the rear mounting bracket to the threaded hole in the frame and the wire nut using (2) M8 hex head bolts, (2) M8 lock washers, and (2) M8 flat washers. Do not fully tighten at this time.
5. Next take the drivers side running board and place it on the running board brackets NOTE : the rubber black out strip is to be removed off of the running boards. Attach the running board to the mounting brackets by sliding the 5/16" square head bolts in the groves in the running boards (2) 5/16" square head bolts will be used per mounting bracket attach using (2) 5/16" flat washers, and (2) 5/16" nylock nuts (fig 4) . Do not fully tighten at this time.

### CARE INSTRUCTIONS

- REGULAR WAXING IS RECOMMENDED. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES
- STAINLESS STEEL PRODUCTS CAN BE CLEANED WITH MILD SOAP AND WATER. STAINLESS STEEL POLISH SHOULD BE USED TO POLISH SMALL SCRATCHES.
- GLOSS BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER

6. Align and adjust step bar as needed, (NOTE : if needed the extra 3/8" washers are used as spacer shims for the brackets) then tighten all hardware at this time. Torque all M8 hardware to 25-30 ft lbs, and 5/16" to 25 ft lbs. repeat steps 1-6 for passenger side.



The M8 nut will be attached here

