



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS



PROFESSIONAL INSTALL RECOMMENDED

2016 CHEVROLET SILVERADO 1500 / 2016 GMC SIERRA 1500

PART#: Z332081 / Z332081-KIT-C

FRONT ROOF LED LIGHT MOUNTS

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.

PARTS INCLUDED

- (1) - Driver Side Roof Mount Upright
- (1) - Passenger Side Roof Mount Upright
- (1) - Driver Side Curved Coupler
- (1) - Passenger Side Curved Coupler
- (1) - Driver Side Straight Coupler
- (1) - Passenger Side Straight Coupler
- (1) - Hardware Pack



* Simulated Rendering, Not actual parts.

LED LIGHTS INCLUDED

Z332081 - No LED Lights Included

Z332081-KIT-C - (1) ZROADZ 50" Curved LED Light Bar

HARDWARE INCLUDED

Z332081

- (1) - Weather Proof Rubber Boot
- (1) - 3/16 DIA. Wire Clip Mount
- (2) - 1/2 x 20 Hex Nut
- (2) - 1/2 Split Lock Washer
- (8) - 10-32 x .562 Button Head Allen Cap
- Stainless Steel Screws
- (8) - 10/32 Nylock Stainless Steel Nuts
- (1) - Driver Side Bottom Plate Gasket
- (1) - Passenger Side Bottom Plate Gasket

Z332081-KIT-C / Z332081-KIT-S

- (1) - Weather Proof Rubber Boot
- (1) - 3/16 DIA. Wire Clip Mount
- (2) - 1/2 x 20 Hex Nut
- (2) - 1/2 Split Lock Washer
- (8) - 10/32 x .562 Button Head Allen Cap
- Stainless Steel Screws
- (8) - 10/32 Nylock Stainless Steel Nuts
- (1) - Driver Side Bottom Plate Gasket
- (1) - Passenger Side Bottom Plate Gasket
- (1) - Torx Bit T-40
- (2) - M8 Tamper Proof Bolt
- (2) - M8 Split Lock Washer

TOOLS REQUIRED

- Tapered 1/2" drill bit or car reamer
- Drill
- Air Hose & Nozzle
- Alcohol Cleaning Solution
- Cleaning Rag
- Socket Set & Ratchet Tool
- Ratchet Extensions
- Various Wrenches
- Dikes or Snips
- Torq Bit Set
- Heat Gun

MATERIALS NEEDED - Clear RTV Silicone
- 1/2" x 1/4" DIA Shrink Tube

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS.
* IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.

LED LIGHT BRACKET INSTALLATION

- STEP 1** 1) Drop OEM headliner down to allow access to the inside of vehicle roof moulding, per industry "R&R" method..



FIG 1

STEP 2

2) From above, remove or push to the side roof seam moulding. (The Black Rubber Strip near both top edges of vehicle cab.)

SEE FIGURE 2



FIG 2



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 3



FIG 4

STEP 3

3) Located closest to the front windshield, remove mounting studs in roof seam channel on driver and passenger side that attach the moulding to the roof. A heavy duty pair of diaks or snips will make quick work to pinch stud off. Make flush with roof channel and then touch up bare metal with paint. Let paint dry.

IMPORTANT NOTE

SEE FIGURE 4

Clear the channel of any obstructions including any channel moulding mounting posts where the bracket will install. If the channel has body seam sealer that does not span the width of the channel it must be removed for the distance that the bracket will come in contact with the roof channel. Replace any seam sealer with RTV silicone (STEP #29) and apply in a manner that yields a flat surface for the gasket to contact the roof.



FIG 5

DRILLING VEHICLE ROOF

STEP 4

SEE FIGURE 5

4) Obtain the supplied roof mount base gaskets to use as a template to locate the drill hole location. Lay the gasket in the roof channel. DO NOT REMOVE THE GASKETS ADHESIVE LINER.

Make sure to gasket is centered transversely (from right to left) in the channel. The front to back location of the gasket should be 1/4" from the top edge of the windshield glass to the end of the front of the gasket.



FIG 6

PRO TIP

DO NOT ATTEMPT INSTALL UNLESS YOU HAVE A CAR REAMER OR TAPERED 1/2" METAL DRILL BIT!

STEP 5

SEE FIGURES 6-7-8-9

5) Using the gasket hole as a locator, center punch the pilot hole location.

With the interior roof free and clear, drill a 1/4" hole in the roof gutter to pilot the mounting hole. Use a car reamer (as seen in Figure #7) or tapered 1/2" metal drill bit to open the hole to a final diameter of 1/2".

With the holes drilled through, clean off all drilling debris and flash INSIDE AND OUTSIDE OF THE DRILL HOLE LOCATIONS. This is a very important to create a flush sealing surface and you do not want to leave any chance of rust occurring. Perform this step for both sides of the roof.



FIG 7



FIG 8

FIG 9

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 10

STEP 6

SEE FIGURES 9 - 12

6) Clean the base of the supplied roof brackets with alcohol. Once dry remove the liner of the base gaskets from step #4 and apply the gasket to the base of each bracket.



FIG 11

STEP 7

SEE FIGURE 13

7) Before you install the bracket to the roof, check that the threads on the post after coming through the roof are clean.



FIG 12

STEP 8

SEE FIGURE 14

8) Use a thin layer of clear RTV Silicone around outside of each drilled hole to help with weather proofing and sealing.

INSTALL ROOF MOUNT TO ROOF



FIG 13



FIG 14

STEP 9

SEE FIGURE 15

9) With the roof and channel area debris free and wiped down clean with alcohol cleaning solution, align the ZROADZ LED Mounting bracket to the roof and insert the through bolt threads down into the drilled hole.

Make sure the outside of the upright is coated black and says ZROADZ while the inside of upright presents the aluminum skin. Inspect your work to make sure you are happy with the position and then repeat for other side.



FIG 15

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 16



FIG 17



FIG 18

STEP 10

SEE FIGURES 16 - 18

10) With the two brackets installed, check that the threads on the post after coming through the roof are clean. Install the split lock washer and the hex nut and tighten securely.

STEP 11

11) Check to make sure the upright is secured and firmly attached to top side of roof.



FIG 19

LED LIGHT INSTALL

STEP 12

SEE FIGURE 19 - 21

12) Obtain the supplied security torx, lock washer and tool bit from the hardware pack. With a friend's help, install the 50" light to the brackets with the wire on the drivers side. Tighten hardware by giving the torx bit some extra leverage.



FIG 20

STEPS 13

SEE FIGURE 22

13) Secure the wire to the driver bracket with supplied wire clip and nut. Leave slack in the wire from LED to the wire clip for some movement & available adjustment.



FIG 21



FIG 22

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 23



FIG 24

STEPS 14

SEE FIGURE 23

14) Cut the LED light wires. Leave enough room for the insulation to be removed and the red and black wires to pass through the roof via the "Through Bolt Down Tube".

STEP 15

SEE FIGURE 24

15) Trim back a large amount of the insulation sheath off the LED Wires so that you can slip them through the rubber weather proofing boot.

To expose the wires, a sharp razor could easily splice open the insulation sheath.

WIRING PLUMBING



FIG 25



FIG 26

STEPS 16

SEE FIGURES 25 & 26

16) Install 1/4" heat shrink insulation over wires as shown in Figure #25. Shrink insulation with heat gun or similar.



FIG 27

STEPS 17

SEE FIGURES 27

17) Use a 50/50 mix of dish soap and water solution to install supplied boot over wire as shown on page #2 Fig. 6.

Pass the wire through the tube. Use a liberal amount of solution on the bracket around the area where the boot installs to aid in slipping the boot over the post.




FIG 28



FIG 29



FIG 30

LED LIGHT BRACKET INSTALLATION - CONTINUED



LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



STEPS 18

SEE FIGURE 31

18) Stuff the boot into the bracket opening and over the down tube upright.

STEP 19

SEE FIGURE 33 - 34

19) With the rubber boot fully seated (as seen in Figures #33 & 34) you are now ready to finish wiring up the LED Light bar to a wiring harness.

After wiring is complete, re-install vehicle's interior in the reverse order it was removed according to industry "R&R" method.

FINAL INSTALLATION



STEP 20



20) Wire LED Light with a ZROADZ optional wiring harness kit (part# Z390020S-A) or by utilizing a compatible custom wiring harness. ZROADZ recommends LED Lights be wired with ZROADZ harness kit (part# Z390020S-A).

STEPS 18

ADJUSTMENT TIPS

21) To adjust the angle of your Light Bar, rotate the LED(s) to adjust the angles till your desired light pattern is reached. There will be minimal adjustment due to curved light bar orientation. You may then tighten the hardware and secure everything into place. Be careful not to over tighten the mounting hardware.

It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed.



LED LIGHT ROOF MOUNT INSTALLATION - COMPLETE